


COMPONENT MAINTENANCE MANUAL WITH IPL

PORTABLE CYLINDER ASSEMBLIES 9700 SERIES AND 9800 SERIES

1-155



35-31-55 T-1 Mar 1/83

### 901

### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL

### RECORD OF REVISIONS

REV NO.	ISSUE DATE	DATE	BY	REV NO.	ISSUE DATE	DATE	вч
1 2 3 4	Sep 30/75 Feb 20/81 Mar 1/83 Dec 20/85						

35-31-55

RR-1

Dec 20/85

## SCOTT

### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL

### RECORD OF TEMPORARY REVISIONS

TEMPORARY REV. NO.	PAGE	DATE	BY	DATE	BY
35-10	1115	Apr 29/77			

35-31-55 TR-1

Mar 1/83

## 900

### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL

### SERVICE BULLETIN LIST

REV	INCORP	BY	NUMBER	REV	INCORP	BY
	Mar 1/83	Scott				
			*			
		1				
		Mar 1/83	Mar 1/83 Scott	Mar 1/83 Scott	Mar 1/83 Scott	

35-31-55

SB-1

Mar 1/83

## HODE

#### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL

### LIST OF EFFECTIVE PAGES

Insert latest revised pages, destroy superseded pages.

\*The asterisk indicates pages revised or added by the current revision...

102 Mar 1/83 103 Mar 1/83 104 Mar 1/83 105 Mar 1/83 106 Mar 1/83 107 Dec 20/85 108 Mar 1/83 109 Mar 1/83 110 Mar 1/83 110 Mar 1/83 301 Mar 1/83 302 Mar 1/83 303 Mar 1/83	SUBJECT	PAGE	DATE
Record of Temporary Revisions Service Bulletin List List of Effective Pages  *LEP-1 Dec 20/85 *LEP-2 Dec 20/85 Table of Contents T/C-1 Table of Contents Introduction Intro-2 Description and Operation  Description and Operation  Intro-2 Intro-2 Intro-3 Intro-2 Intro-3 Intro-3 Intro-3 Intro-4 Intro-6 Intro-7 Intro-7 Intro-7 Intro-7 Intro-7 Intro-8 Intro-8 Intro-9 In	Title	T-1	Mar 1/83
Service Bulletin List	Record of Revisions	≠RR-1	Dec 20/85
List of Effective Pages #LEP-1 Dec 20/85  **LEP-2 Dec 20/85  Table of Contents T/C-1 Mar 1/83  Introduction INTRO-1 Mar 1/83  Description and Operation 1 Mar 1/83  **3 Dec 20/85  **4 Mar 1/83  **5 Mar 1/83  **5 Mar 1/83  **5 Mar 1/83  **6 Mar 1/83  **8 Mar 1/83  **10 Mar 1/83  **11 Mar 1/83  **10 Mar 1/83  **11 Mar 1/83  **10 Mar 1/83  **107 Dec 20/85  **108 Mar 1/83  **109 Mar 1/83  **109 Mar 1/83  **100 Mar 1/83  **101 Mar 1/83  **102 Mar 1/83  **103 Mar 1/83  **104 Mar 1/83  **105 Mar 1/83  **106 Mar 1/83  **107 Dec 20/85  **108 Mar 1/83  **109 Mar 1/83  **100 Mar 1/83  **101 Mar 1/83  **101 Mar 1/83  **102 Mar 1/83  **103 Mar 1/83  **104 Mar 1/83  **105 Mar 1/83  **107 Dec 20/85  **108 Mar 1/83  **109 Mar 1/83  **101 Mar 1/83  **102 Mar 1/83  **103 Mar 1/83  **104 Mar 1/83  **105 Mar 1/83  **107 Dec 20/85  **108 Mar 1/83  **109 Mar 1/83  **100 Mar 1/83  **101 Mar 1/83  **102 Mar 1/83  **103 Mar 1/83  **104 Mar 1/83  **105 Mar 1/83  **107 Dec 20/85  **108 Mar 1/83  **109 Mar 1/83  **101 Mar 1/83  **102 Mar 1/83  **103 Mar 1/83	Record of Temporary Revisions	TR-1	Mar 1/83
Table of Contents T/C-1 Mar 1/83 Introduction INTRO-2 Mar 1/83 Description and Operation 1 Mar 1/83  Description and Operation 2 Mar 1/83  #3 Dec 20/85  #4 Mar 1/83  #5 Dec 20/85  #4 Mar 1/83  #5 Mar 1/83  #6 Mar 1/83  #7 Mar 1/83  #8 Mar	Service Bulletin List	SB-1	Mar 1/83
Table of Contents Introduction INTRO-1 INTRO-2 Mar 1/83 INTRO-2 Mar 1/83 INTRO-2 Mar 1/83 INTRO-2 Mar 1/83  2 Mar 1/83  3 Dec 20/85 4 Mar 1/83 5 Mar 1/83 5 Mar 1/83 6 Mar 1/83 7 Mar 1/83 8 Mar 1/83 9 Mar 1/83 10 Mar 1/83 11 Mar 1/83 12 Blank Testing and Fault Isolation  **101 Dec 20/85 Mar 1/83 103 Mar 1/83 104 Mar 1/83 105 Mar 1/83 106 Mar 1/83 107 Dec 20/85 108 Mar 1/83 109 Mar 1/83 109 Mar 1/83 109 Mar 1/83 109 Mar 1/83 100 Mar 1/83 100 Mar 1/83 101 Mar 1/83 105 Mar 1/83 106 Mar 1/83 107 Mar 1/83 108 Mar 1/83 109 Mar 1/83 110 Mar 1/83	List of Effective Pages	*LEP-1	Dec 20/85
Introduction INTRO-1 Mar 1/83 INTRO-2 Mar 1/83 Description and Operation 1 Mar 1/83 2 Mar 1/83 3 Dec 20/85 4 Mar 1/83 5 Mar 1/83 6 Mar 1/83 7 Mar 1/83 8 Mar 1/83 9 Mar 1/83 10 Mar 1/83 11 Mar 1/83 11 Mar 1/83 11 Mar 1/83 12 Blank Testing and Fault Isolation *101 Dec 20/85 102 Mar 1/83 103 Mar 1/83 104 Mar 1/83 105 Mar 1/83 106 Mar 1/83 107 Dec 20/85 108 Mar 1/83 109 Mar 1/83 1006 Mar 1/83 1007 Dec 20/85 108 Mar 1/83 109 Mar 1/83 100 Mar 1/83		*LEP-2	Dec 20/85
Description and Operation 1 1 1/83 2 Mar 1/83 2 Mar 1/83 3 Dec 20/85 4 Mar 1/83 5 Mar 1/83 6 Mar 1/83 7 Mar 1/83 8 Mar 1/83 9 Mar 1/83 10 Mar 1/83 11 Mar 1/83 12 Blank Testing and Fault Isolation *101 Dec 20/85 102 Mar 1/83 103 Mar 1/83 104 Mar 1/83 105 Mar 1/83 106 Mar 1/83 106 Mar 1/83 107 Dec 20/85 108 Mar 1/83 109 Mar 1/83 100 Mar 1/83 100 Mar 1/83 100 Mar 1/83 101 Mar 1/83 102 Mar 1/83 103 Mar 1/83 104 Mar 1/83 105 Mar 1/83 106 Mar 1/83 107 Dec 20/85 108 Mar 1/83 109 Mar 1/83	Table of Contents	T/C-1	Mar 1/83
Description and Operation 1 Mar 1/83 2 Mar 1/83 bec 20/85 4 Mar 1/83 5 Mar 1/83 6 Mar 1/83 6 Mar 1/83 7 Mar 1/83 8 Mar 1/83 9 Mar 1/83 10 Mar 1/83 11 Mar 1/83 11 Mar 1/83 12 Blank 12 Blank 12 Blank 12 Blank 102 Mar 1/83 103 Mar 1/83 103 Mar 1/83 104 Mar 1/83 105 Mar 1/83 105 Mar 1/83 105 Mar 1/83 106 Mar 1/83 106 Mar 1/83 107 Dec 20/85 108 Mar 1/83 109 Mar 1/83 100 M	Introduction	INTRO-1	Mar 1/83
2 Mar 1/83		INTRO-2	Mar 1/83
#3 Dec 20/85 4 Mar 1/83 5 Mar 1/83 6 Mar 1/83 7 Mar 1/83 8 Mar 1/83 9 Mar 1/83 10 Mar 1/83 11 Mar 1/83 11 Mar 1/83 12 Blank 12 Blank 102 Mar 1/83 103 Mar 1/83 104 Mar 1/83 105 Mar 1/83 106 Mar 1/83 107 Dec 20/85 108 Mar 1/83 109 Mar 1/83 109 Mar 1/83 109 Mar 1/83 100 Mar 1/83 100 Mar 1/83 101 Mar 1/83 102 Mar 1/83 103 Mar 1/83 104 Mar 1/83 105 Mar 1/83 106 Mar 1/83 107 Dec 20/85 108 Mar 1/83 109 Mar 1/83 100 Mar 1/83 100 Mar 1/83 100 Mar 1/83 100 Mar 1/83 110 Mar 1/83	Description and Operation	1	Mar 1/83
### Table		2	Mar 1/83
5 Mar 1/83 6 Mar 1/83 7 Mar 1/83 8 Mar 1/83 9 Mar 1/83 10 Mar 1/83 11 Mar 1/83 12 Blank Testing and Fault Isolation *101 Dec 20/85 102 Mar 1/83 103 Mar 1/83 104 Mar 1/83 105 Mar 1/83 106 Mar 1/83 107 Dec 20/85 108 Mar 1/83 109 Mar 1/83 110 Mar 1/83		*3	Dec 20/85
6 Mar 1/83 7 Mar 1/83 8 Mar 1/83 9 Mar 1/83 10 Mar 1/83 11 Mar 1/83 12 Blank Testing and Fault Isolation *101 Dec 20/85 102 Mar 1/83 103 Mar 1/83 104 Mar 1/83 105 Mar 1/83 106 Mar 1/83 107 Dec 20/85 108 Mar 1/83 109 Mar 1/83 100 Mar 1/83 110 Mar 1/83		4	Mar 1/83
7 Mar 1/83 8 Mar 1/83 9 Mar 1/83 10 Mar 1/83 11 Mar 1/83 12 Blank Testing and Fault Isolation *101 Dec 20/85 102 Mar 1/83 103 Mar 1/83 104 Mar 1/83 105 Mar 1/83 106 Mar 1/83 106 Mar 1/83 106 Mar 1/83 107 Dec 20/85 108 Mar 1/83 109 Mar 1/83 109 Mar 1/83 109 Mar 1/83 100 Mar 1/83 110 Mar 1/83		5	Mar 1/83
8 Mar 1/83 9 Mar 1/83 10 Mar 1/83 11 Mar 1/83 11 Mar 1/83 12 Blank Testing and Fault Isolation *101 Dec 20/85 102 Mar 1/83 103 Mar 1/83 104 Mar 1/83 105 Mar 1/83 106 Mar 1/83 106 Mar 1/83 107 Dec 20/85 108 Mar 1/83 109 Mar 1/83 110 Mar 1/83		6	Mar 1/83
9 Mar 1/83 10 Mar 1/83 11 Mar 1/83 12 Blank 12 Blank 102 Mar 1/83 103 Mar 1/83 104 Mar 1/83 105 Mar 1/83 106 Mar 1/83 106 Mar 1/83 107 Dec 20/85 108 Mar 1/83 109 Mar 1/83 110 Mar 1/83		7	Mar 1/83
10 Mar 1/83 11 Mar 1/83 12 Blank 12 Blank 101 Dec 20/85 102 Mar 1/83 103 Mar 1/83 104 Mar 1/83 105 Mar 1/83 106 Mar 1/83 107 Dec 20/85 108 Mar 1/83 109 Mar 1/83 110 Mar 1/83		8	Mar 1/83
11 Mar 1/83 12 Blank Testing and Fault Isolation *101 Dec 20/85 102 Mar 1/83 103 Mar 1/83 104 Mar 1/83 105 Mar 1/83 106 Mar 1/83 107 Dec 20/85 108 Mar 1/83 109 Mar 1/83 109 Mar 1/83 110 Mar 1/83		9	Mar 1/83
Testing and Fault Isolation #101 Dec 20/85  102 Mar 1/83 103 Mar 1/83 104 Mar 1/83 105 Mar 1/83 106 Mar 1/83 107 Dec 20/85 108 Mar 1/83 109 Mar 1/83 109 Mar 1/83 100 Mar 1/83 110 Mar 1/83		10	Mar 1/83
Testing and Fault Isolation *101 Dec 20/85  102 Mar 1/83 103 Mar 1/83 104 Mar 1/83 105 Mar 1/83 106 Mar 1/83 *107 Dec 20/85 108 Mar 1/83 109 Mar 1/83 110 Mar 1/83 110 Mar 1/83 110 Mar 1/83 110 Mar 1/83 302 Mar 1/83 303 Mar 1/83		11	Mar 1/83
102 Mar 1/83 103 Mar 1/83 104 Mar 1/83 105 Mar 1/83 106 Mar 1/83 107 Dec 20/85 108 Mar 1/83 109 Mar 1/83 110 Mar 1/83 110 Mar 1/83 301 Mar 1/83 302 Mar 1/83 303 Mar 1/83		12	Blank
103 Mar 1/83 104 Mar 1/83 105 Mar 1/83 106 Mar 1/83 *107 Dec 20/85 108 Mar 1/83 109 Mar 1/83 110 Mar 1/83 110 Mar 1/83 301 Mar 1/83 302 Mar 1/83 303 Mar 1/83	Testing and Fault Isolation	*101	Dec 20/85
104 Mar 1/83 105 Mar 1/83 106 Mar 1/83 *107 Dec 20/85 108 Mar 1/83 109 Mar 1/83 110 Mar 1/83 110 Mar 1/83 301 Mar 1/83 302 Mar 1/83 303 Mar 1/83		102	Mar 1/83
105 Mar 1/83 106 Mar 1/83 *107 Dec 20/85 108 Mar 1/83 109 Mar 1/83 110 Mar 1/83 110 Mar 1/83 301 Mar 1/83 302 Mar 1/83 303 Mar 1/83		103	Mar 1/83
106 Mar 1/83 *107 Dec 20/85 108 Mar 1/83 109 Mar 1/83 110 Mar 1/83 110 Mar 1/83 301 Mar 1/83 302 Mar 1/83 303 Mar 1/83		104	Mar 1/83
*107 Dec 20/85 108 Mar 1/83 109 Mar 1/83 110 Mar 1/83 110 Mar 1/83 301 Mar 1/83 302 Mar 1/83 303 Mar 1/83		105	Mar 1/83
108 Mar 1/83 109 Mar 1/83 110 Mar 1/83 Disassembly 301 Mar 1/83 302 Mar 1/83 303 Mar 1/83		106	Mar 1/83
109 Mar 1/83 110 Mar 1/83 301 Mar 1/83 302 Mar 1/83 303 Mar 1/83		*107	Dec 20/85
Disassembly 301 Mar 1/83 302 Mar 1/83 303 Mar 1/83		108	Mar 1/83
Disassembly 301 Mar 1/83 302 Mar 1/83 303 Mar 1/83		109	Mar 1/83
302 Mar 1/83 303 Mar 1/83			Mar 1/83
303 Mar 1/83	Disassembly		
304 Mar 1/87			
204 Mai 1703		304	Mar 1/83

## HODE

### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL

### LIST OF EFFECTIVE PAGES (Continued)

SUBJECT	PAGE 401	MAT 1/83
	402	Mar 1/83
	403	Mar 1/83
	404	Mar 1/83
Check	*501	Dec 20/85
	502	Blank
Repair	<b>±601</b>	Dec 20/85
	602	Mar 1/83
Assembly	*701	Dec 20/85
	702	Mar 1/83
	*703	Dec 20/85
	*704	Dec 20/85
	<b>±705</b>	Dec 20/85
	*706	Dec 20/85
Fits and Clearances	801	Mar 1/83
	802	Blank
Special Tools, Fixtures and Test	901	Mar 1/83
Equipment	902	Blank
Illustrated Parts List	1001	Mar 1/83
	1002	Mar 1/83
	1003	Mar 1/83
	1004	Mar 1/83
	*1005	Dec 20/85
	1006	Mar 1/83
	1007	Mar 1/83
	1008	Mar 1/83
	*1009	Dec 20/85
	1010	Mar 1/83
	1011	Mar 1/83
	1012	Mar 1/83
	1013	Mar 1/83
	-1014	Dec 20/85
	1015	Mar 1/83
	1016	Mar 1/83
	1017	Mar 1/83
	1018	Mar 1/83
	1019	Mar 1/83
	1020	Mar 1/83
	1021	Mar 1/83
	*1022	Dec 20/85
	1023	Mar 1/83
	1024	Blank

35-31-55

LEP-2 Dec 20/85

## SOU

#### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL

#### TABLE OF CONTENTS

Subject	Page
Description and Operation	1
Testing and Trouble Shooting	101
Disassembly	301
Cleaning	401
Check	501
Repair	601
Assembly	701
Fits and Clearances	801
Special Tools, Fixtures and Test Equipment	901
Illustrated Parts List	1001

### STOTE

#### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL

#### INTRODUCTION

This manual establishes the proper maintenance procedures which shall be followed by user maintenance, overhaul and service personnel when performing any type of service on the 9700 & 9800 series Portable Cylinder Assemblies described herein.

It is the primary intent of this manual:

- a. To specify proper safety regulations to be followed during performance of service on oxygen equipment used in aviation applications.
- b. To establish proper sequence of operations to be performed on the defined equipment.
- c. To provide the user with the data necessary to properly maintain, check, test and repair the equipment.

The following WARNINGS are presented to inform the user of this manual of the requirements which shall be adhered to when performing service procedures on this equipment. Additional WARNINGS will be found in the procedural steps in the manual.

- WARNINGS:

  ANY SERVICE OR OVERHAUL PERFORMED ON THIS APPARATUS SHALL BE DONE ONLY BY THOSE FACILITIES EXPERIENCED IN, OR BY PERSONNEL KNOWLEDGEABLE IN AVIATION OXYGEN EQUIPMENT. IF NONE ARE KNOWN, CONTACT SCOTT AVIATION OR ITS DISTRIBUTORS FOR NAMES OF AUTHORIZED SERVICE CENTERS.
- WARNINGS:

  ALL PROCEDURES DESCRIBED IN THIS MANUAL SHALL BE PERFORMED IN AN AREA FREE OF OIL, GREASE, FLAMMABLE SOLVENTS OR OTHER COMBUSTIBLE MATERIALS. SUCH MATERIALS, AS WELL AS DUST, LINT, AND FINE METAL FILINGS ARE ALL POTENTIAL COMBUSTIBLES WHICH MIGHT, WHEN EXPOSED TO OXYGEN UNDER PRESSURE IGNITE AND RESULT IN AN EXPLOSION AND/OR FIRE.
- WARNINGS:

  DO NOT ALLOW OIL, GREASE, FLAMMABLE SOLVENTS, OR OTHER COMBUSTIBLE MATERIALS TO COME IN CONTACT WITH PARTS THAT WILL BE EXPOSED TO PRESSURIZED OXYGEN. SUCH MATERIALS, AS WELL AS DUST, LINT, AND FINE METAL FILINGS ARE ALL POTENTIAL COMBUSTIBLES WHICH MIGHT, WHEN EXPOSED TO OXYGEN UNDER PRESSURE, IGNITE AND RESULT IN AN EXPLOSION.

# SCOTT

#### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL

### Verification

Section	Date
Testing and Fault Isolation	October 14, 1982
Disassembly	October 14, 1982
Assembly	October 14, 1982

## STOTE

#### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL

#### PORTABLE OXYGEN BREATHING EQUIPMENT

#### DESCRIPTION AND OPERATION

#### 1. General

- A. This manual provides overhaul instructions with illustrated parts list for the 9700 series and 9800 series Portable Cylinder Assemblies.
- B. The instructions in this manual apply to all assemblies unless specific reference is made to a particular part number.
- C. Each of the various assemblies (see figure 1) consists of an oxygen cylinder (1), pressure regulator (2), "ON-OFF" valve (3), relief valve (4), safety outlet assembly (5), charging valve (6), mask outlet assembly (7), and gauge (8). In addition, the 9800 series contains a demand type oxygen regulator (9). The part number of a particular assembly is determined by the part numbers of the various components that make up the assembly.
- Leading Particulars. Refer to figures 2 and 3 for leading particulars.

#### 3. Purpose of Equipment

A. This equipment provides a portable oxygen breathing source. The 9700 series contains outlet assemblies used to adapt a rebreather type mask. The rebreather type mask provides the user with supplementary oxygen for high altitude breathing and/or therapeutic use. The 9800 series provides oxygen for the above uses and, in addition, provides a walk-around oxygen supply for a demand type mask suitable for smoke and fume protection.

#### 4. Typical Installation


A. All assemblies are completely portable and have a carrying strap. They should be stored in a convenient and accessible location.

#### 5. Overall Operation

A. Oxygen is supplied from the high pressure cylinder to the pressure regulator. The "ON-OFF" valve, safety outlet assembly and pressure gauge are exposed to cylinder pressure. The "ON-OFF" valve controls the flow of oxygen from the cylinder to

### HILL


### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL



Portable Cylinder Assemblies Figure 1

## IIII

9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL




Leading Particulars of 9700 Series Figure 2

35-31-55

Page 3 Dec 20/85

## TIME

9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL



Leading Particulars of 9800 Series Figure 3

> 35-31-55 Page 4 Mar 1/83

## SIDIL

#### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL

the pressure reducing mechanism in the regulator body. It also controls the flow of oxygen from the charging valve to the cylinder. When the valve is in the "OFF" position, oxygen cannot flow through the regulator. The safety outlet assembly contains a frangible disc. In the event of hazardous pressure rise, the frangible disc ruptures and allows cylinder oxygen to be vented to atmosphere.

- 8. When the "ON-OFF" valve is open, oxygen flows into the upper portion of the regulator body which contains the pressure reducing mechanism. It reduces the cylinder oxygen pressure to a lower pressure which is suitable to supply a rebreather type mask, through the outlet assemblies, or a demand type regulator.
- C. The regulator contains a valve assembly which enables the cylinder to be filled (recharged) with high pressure oxygen. A relief valve is located in the low pressure portion of the regulator to protect the low pressure section from a hazardous pressure buildup.

## TIME

# 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL


#### 6. Detailed Operation

- A. "ON-OFF" Valve. "ON-OFF" valve (3, figure 4) is a rotary type valve installed in the high pressure portion of the pressure regulator. Rotation of the valve knob in a clockwise direction causes the valve head assembly to seat against a port in the regulator body, thus preventing flow to the upper portion of the regulator. Rotation of the knob in a counterclockwise direction opens the port and allows oxygen to enter the pressure regulating mechanism.
- B. Safety Outlet Assembly. Safety outlet assembly (4, figure 4) is installed in the high pressure portion of the regulator. The center of the outlet contains a frangible disc. In the event of hazardous cylinder pressure rise, the frangible disc ruptures and allows the oxygen to vent to atmosphere.
- C. Pressure Gauge. Pressure gauge (8, figure 1) is installed in the high pressure portion of the regulator. It indicates the pressure of the oxygen in the cylinder, thus giving an indication of the amount of available oxygen.
- D. Pressure regulator. Pressure regulator (see figure 4) reduces high pressure oxygen to a lower pressure. When the "ON-OFF" valve is open, oxygen flows to the top portion of the regulator. This portion of the regulator contains the pressure reducing mechanism. It performs in the following manner. High pressure oxygen and spring (9) act upward on thrust pin (10). These forces act to seat the pin against valve seat (11) to prevent flow through the regulator. The other end of the pin rests against thrust plate (12) and diaphragm (13). One side of the diaphragm is acted upon by spring (14) and the other side is acted upon by outlet pressure. The spring acts downward and tends to move thrust pin (10) away from seat (11). Outlet oxygen pressure acts upward on the diaphragm to counter the spring force. Oxygen will flow through the regulator as long as the force of spring (14) exceeds the outlet pressure acting on diaphragm (14) and the forces tending to move thrust pin (10) against its seat. However, as increasing outlet pressure counter-balances spring (14), thrust pin (10) is forced toward its seat by inlet oxygen pressure and spring (9) until a condition of equilibrium is established and regulator pressure is maintained. Spring (14) is preset to maintain an outlet pressure of approximately 55 osi.

Mar 1/83

### गा

### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL



Regulator Cross Section Figure 4


35-31-55
Page 7

Page 7 Mar 1/83

## SUU


#### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL

E. Charging Valve Assembly. Charging valve assembly (see figure 5) is used to fill the oxygen cylinder with high pressure oxygen. Since it is located in the upper portion of the regulator, the "ON-OFF" valve must be open to allow oxygen to flow into the cylinder. High pressure oxygen applied at charging valve inlet (1) forces valve (2) away from its seat, and oxygen flows through porting into the high pressure cylinder. The valve seats against its housing to prevent flow out of the cylinder. A cap installed on the charging valve prevents seepage past valve (2) and dirt from entering.



Charging Valve Assembly Figure 5

F. Relief Valve. Relief valve (see figure 6) is installed in the low pressure portion of the regulator. The relief valve serves as a safety device to prevent excessive outlet pressure. In the event of excessive outlet pressure, poppet assembly (1) is forced away from its seat in body (2), and oxygen is vented through the openings in the body. When pressure reduces to an acceptable value, spring (3) forces the poppet against its seat, thus stopping the flow of oxygen.



Relief Valve Figure 6


## SWII

### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL

- G. Outlet Assemblies. Six different outlet assemblies are available. The type used on a particular installation is dependent on flow requirements and the type of mask insert to be used. Each outlet is similar in that it contains an internal check valve and an oxygen hose plug-in adapter. Three of the outlets contain glass wool for metering flow. When a plug-in is inserted in an outlet, it opens the check valve and allows flow into a mask.
- H. Two outlet assemblies are provided on most 9700 series assemblies although one and three outlets may also be found. The 9800 series may contain one outlet assembly, two outlet assemblies or no outlet assembly. The six different outlet assemblies are illustrated in figure 7.
- J. Demand Regulator. (See figure 8.) The 9800 series contains a demand type regulator. The inlet of the regulator is connected to one of the pressure reducer outlet openings. The demand regulator allows oxygen to flow, on demand, to a demand type mask. Inhalation in the demand mask withdraws oxygen from the body of the demand regulator. This causes a pressure drop in the regulator case which allows atmospheric pressure, acting on the outside of diaphragm (1), to force the diaphragm inward against the stem of valve (2). This action opens the valve and causes oxygen to enter the regulator body, thus raising the pressure in the regulator body. The increased pressure moves the diaphragm away from the valve stem, thus stopping the flow of oxygen. The regulator functions in this manner to supply oxygen on demand.

### 900

### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL




Available Outlet Assemblies with Plug-Ins Figure 7

35-31-5= Page 10 Mar 1/83

## STOTE

### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL



Pemand Regulator Figure 8

## SWII

### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL

#### TESTING AND FAULT ISOLATION

#### 1. Testing

WARNING:

IN ALL PROCEDURES LISTED BELOW, OXYGEN IS SPECIFIED AS THE TEST GAS. WATER PUMPED NITROGEN OR OIL-FREE AIR MAY BE SUBSTITUTED, BUT RESULTS MUST BE CONVERTED PRIOR TO BEING COMPARED WITH THE RESULTS SPECIFIED FOR OXYGEN. DO NOT, UNDER ANY CIRCUMSTANCES, USE OIL PUMPED GAS AS THIS WILL CAUSE CONTAMINATION OF THE REGULATOR AND TEST EQUIPMENT. OIL, EVEN IN MINUTE QUANTITY, COMING IN CONTACT WITH OXYGEN MAY CAUSE AN EXPLOSION OR FIRE.

A. Using the material listed in Table 101, perform the testing procedures outlined in the following paragraphs.

NOTE: Equivalent materials may be used.

MATERIAL	DESCRIPTION	MANUFACTURER*	REFER TO TESTING PARAGRAPH
Oxygen	MIL-0-27210, Type I	V07098	ALL
Leak Test Solution	Snoop MIL-L-25567	V18034	1.D.(2), 1.F.(12), 1.G.(3), 1.H.(5)

\*Refer to Illustrated Parts List, paragraph 1.E, for Vendor's Code

# List of Consumable Materials for Testing Table 101

- B. All tests must be conducted with a cylinder pressure of 1800 psi. Fully charge the cylinder to 1800 psi in accordance with the following instructions.
  - (1) Check the pressure shown on the pressure gauge. If it indicates less than 1800 psi, the cylinder should be charged.
  - (2) Use an oxygen charging system as shown in figure 101 (or equivalent).
  - (3) Open the "ON-OFF" valve fully, and remove the cap from the charging valve.
  - (4) Connect the supply cylinder set-up (see figure 101) to the charging valve.


## STOTE

# 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL

(5) Slowly open the supply cylinder valve, charging at a rate not to exceed 300 psi per minute. Compare the indications of the gauge on the unit and the gauge of the supply cylinders. When the pressure in the breathing oxygen cylinder equals the supply cylinder pressure, close the supply cylinder valve. Allow the cylinder to cool, and recheck the pressure indicated on the pressure gauge. The cylinder should contain 1800 psi at not over 70°F.

### C. Relief Valve

- (1) Connect the relief valve to a suitable oxygen pressure source.
- (2) Apply 90 psi to the relief valve. Valve must hold 90 psi.
- (3) Increase pressure to 135 psi. Relief valve must flow fully.
- (4) Reduce pressure to 90 psi. Valve must reseat.



- 1. SUPPLY CYLINDERS
- 2. TEE, P/N 6258
- 3. TEE, P/N 6145
- 4. PIGTAIL, P/N 5082
- 5. OXYGEN GAUGE 0-2000 PSI

- 6. REFILL COUPLING, P/N 5020-1
- 7. CONNECT CHARGING VALVE OF PORTABLE BREATHING UNIT TO REFILL COUPLING

Setup for Recharging Portable Cylinder Assemblies Figure 101

## डाणा

#### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL

#### D. Outlet Assemblies

- (1) Connect the outlet assembly to an oxygen pressure source.
- (2) Apply 55 ± 2 psi to the outlet assembly and apply leak test solution to all body joints and the outlet port. Bubbles indicate leaks which must be corrected.
- (3) Insert the appropriate mask plug-in into the outlet. The plug-in must be securely held and allow oxygen to flow.
- (4) Shut off the oxygen supply to the outlet assembly. Connect a suitable flow meter to the mask plug-in. Apply an inlet pressure of 55 ± 2 psi. The flow for a particular outlet is determined by the coding of the 9700 or 9800 part numbers (see figures 2 and 3) of which the outlet is a part. This code is also stamped on the hexagon base of each outlet. When flow settings differ on outlets of one 9700 or 9800 unit, "LO" flow and "HI" flow are indicated on the appropriate outlet assemblies. At ground level, outlet flows must agree with the values listed in figure 102 for the particular flow and altitude markings. If flows do not agree, adjust the outlet assembly in accordance with the following instructions.

## आध

### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL

•	REQUIRED FLOW SETT LPM-NTPD (760 m TOLERANCE	m Hg & 20°C)
FLOW RATE AT ALTITUDE	ALTITU	DE - FEET
LPM-STPD (760 mm Hg & O°C)	20,000	23,000
2.0	2.80	2.82
3.0	4.08	4.12
4.0	5.21	5.27

Outlet Assembly Setting Figure 102

- (a) Remove the oxygen supply from the outlet assembly.
- (b) Flow adjustment is accomplished by compressing the cord. This is done by threading the adjusting screw into the outlet. This action serves to decrease flow. Adjust and test outlets until desired flow is obtained.


NOTE: Since the cord will not expand once compressed, removal of adjusting screw will not alter flow. Adjustment should be done with care. The only method for increasing flow is to remove the compressed cord and repack the outlet assembly.

- E. 801242 Series Demand Regulator Test. (See figure 103.)
  - (1) Connect an assembled regulator to the test setup shown in figure 103.
  - (2) With inlet pressure of 35 psi, adjust flow control valve for a minimum flow of 20 liters per minute. Resistance, indicated on draft gauge, shall not be greater than 0.7 inches of water.

NOTE: The regulated inlet pressure shall be maintained during test.

## MILLE

### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL



Test Setup for Demand Regulator P/N 6379 Figure 103

F. 801160 Series Regulator Adjustment and Test

NOTE: Before testing the regulator assembly, make sure it is completely assembled with the specified components.

- (1) Remove relief valve from regulator and install a 0-100 psig pressure gauge in its place.
- (2) Turn the regulator on-off valve to the "ON" position then turn the valve to the "OFF" position.
- (3) Vent the regulated pressure section of the regulator by engaging a mask plug—in into an outlet and letting the oxygen vent. If no constant flow outlet is used on the regulator, attach a threaded adapter and needle valve to one of the plugged outlet ports. Vent through the needle valve.
- (4) Repeat steps (2) and (3) a total of ten times.

## SOUT

#### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL

- (5) Adjust the regulator outlet pressure by turning setscrew (34, IPL figure 7) as necessary to obtain 55 ± 2 psi pressure as indicated on the gauge attached to the regulator relief valve port. Regulator must be flowing through an outlet while the pressure is being adjusted. If no outlet is being used, use an adapter and needle valve (cleaned for oxygen service) and flow approximately 4 LPM.
- (6) Connect a 10 liter per minute flowmeter to a suitable mask plugmin and turn the on-off valve to the "ON" position, then connect the mask plugmin to an outlet. Flow, as indicated on the attached flowmeter, must be in accordance with figure 182.
- (7) Remove the mask plug-in and check the regulator outlet pressure. Lock-up pressure shall not exceed 75 psi.
- (8) Repeat steps (5) through (7) for each additional outlet assembly.
- (9) Turn the regulator on-off valve to the "OFF" position and replace the O-100 psi pressure gauge with the regulator relief valve.
- (10) Repeat steps (1) through (9) a total of three times at 24 hour intervals. Then torque the relief valve per Table 801.
  - NOTE: The 24-hour time interval is recommended to permit component parts to settle.
- (11) Turn the regulator on-off valve to the "ON" position.
- (12) Use leak test solution to leak test all regulator joints and outlet ports. Manipulate mask plugmin to simulate use during test. No leakage is allowed. If outlets, gauge or relief valve joints leak, retorque until leak is eliminated. Maximum torque must not exceed values listed in Table 801. If charging valve assembly leaks, retorque until leak is eliminated. Maximum torque must not exceed value listed in Table 801.

NOTE: Always relieve pressure when retorquing fittings.

#### G. Valve Torque Test

- (1) Using torque wrench, turn on-off valve approximately one full turn open. Required torque shall not exceed 16 lbf.in. (1.80 N·m).
- (2) Using torque wrench, close valve with 16 lbf.in. (1.80 N.m) torque maximum.

## प्राप

#### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL

- (3) Test for leakage through valve by applying leak test solution to the outlet of a mating connector inserted into one of the regulator outlets. After relieving of residual pressure, there shall be no leakage through test connector.
- H. Final Test of Complete Unit
  - (1) Turn the regulator on-off valve to the "ON" position.
  - (2) Immerse the cylinder regulator in a suitable corrosion inhibiting leak test solution. Check for leakage at the On-Off valve stem while turning the valve to "OFF" position and from fully "OFF" back to "ON". No leakage is allowed.
  - (3) Store the unit for seventy-two hours with the regulator On-Off valve in the "ON" position.
  - (4) Repeat step (2).
  - (5) Insert a mask connector in each constant flow outlet. Using leak test solution, check for leakage between connector and outlet. No leakage is allowed.

# SWII

#### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL

### 2. Fault Isolation

A. See figure 104 for a chart containing troubles, probable causes and remedies.

TROUBLE	PROBABLE CAUSE	REMEDY
Relief valve (31, IPL figure 7) does not relieve at proper pressure	Worn parts, contamination	Replace relief
Outlet assembly (29, IPL figure 1) does not allow proper flow	Out of adjustment	Readjust per Testing, paragraph C.(4)
proper rece	Contamination on glass cord	Clean outlet and replace cord
Outlet assembly (29) does not hold plug-in securely	Worn parts	Inspect parts; re- place as necessary
	Parts not properly assembled	Disassemble parts and reassemble properly per Assembly, paragraph A.
Demand regulator (20) fails to meet draft	Demand valve assembly (14, IPL figure 2) sticking	Replace demand valve assembly
and flow requirements	Diaphragm (10) punctured	Install new diaphrage per Assembly, paragraph C.(5)
	Diaphragm (10) not properly assembled to case (22)	Reinstall diaphragm per Assembly, para- graph C.(5)
Demand regulator (20) leaks	Contamination on gasket (18)	Disassemble demand valve assembly and clean
	Defective demand valve assembly (14) or gasket (18)	Replace valve assembly (14, IPL figure 2) and/or gasket (18)

Trouble Shooting Figure 104 (Sheet 1 of 3)

## SIDII

### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL

TROUBLE	PROBABLE CAUSE	REMEDY
Regulator assembly (39, IPL figure 1) fails to provide proper outlet	Regulator assembly not ad- justed properly	Readjust regulator per Testing paragraph E.
pressure	Defective seat (43, IPL figure 6) or pin (44)	Inspect seat and pin per Assembly, paragraph B.(15)
	Diaphragm (40) defective	Replace diaphragm
	Diaphragm (40) not sealed to body	Reassemble diaphragm per Assembly, para- graph B.(17)
Leakage at joint between outlet assembly (29, IPL figure 1) relief valve (31, IPL figure 7) or gauge (30) and body (50)	Units not assembled to body using sealing tape	Reassemble to body per Assembly, paragraph B.(2), B.(5) or B.(6)
	Units not tight enough in body	Retorque per Table 801
Leakage at joint between charging valve assembly (21) body and body (50)	Unit not assembled to body using sealing tape	Reassemble to body per Assembly, paragraph B. (3)
	Unit not tight enough in body	Retorque per Table 801
Leakage at joint between safety plug (28) and	Unit not tight enough in body	Retorque per Table 801
body (50)	Defective disc (26) or gasket (27)	Inspect periphery of gasket and disc for smoothness. Replace if neces- sary and torque per Table 801
Leakage at joint between bushing (17, IPL figure	Unit not tight enough in body	Tighten unit on body
7) and body (50)	Defective packing (16, IPL figure 7)	Replace packing

Trouble Shooting Figure 104 (Sheet 2 of 3)

35-31-55

## IIIP

### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL

TROUBLE	PROBABLE CAUSE	REMEDY	
Leakage past core of charging valve assembly (21)	Loose or defective core	Replace charging valve assembly (21)	
Leakage between bushing	Loose packing nut (11)	Tighten nut	
(17) and packing nut (11)	Defective packing (12)	Replace packing per Assembly, paragraph B.(11)	
Leakage between stem assembly (13) and pack- ing nut (11)	Faulty seat (14)	Replace seat	
On-off valve fails to shut off oxygen in "OFF" position	Faulty head assembly (15)	Replace head assembly per Assembly, para- graph B.(9)	

Trouble Shooting Figure 104 (Sheet 3 of 3)

## भाग

#### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL

#### DISASSEMBLY

WARNING: THE OXYGEN CYLINDER MUST BE COMPLETELY DISCHARGED PRIOR TO PERFORMING ANY DISASSEMBLY.

NOTE: See Testing and Fault Isolation, to establish the condition of the unit or most probably cause of its malfunction. This is to determine the extent of disassembly required without completely tearing down and rebuilding the unit.

NOTE: The instructions in paragraphs 1 and 2 list the steps necessary to disassemble each of the Portable Cylinder Assemblies into major components. Instructions for disassembly of the components are listed in paragraphs 3 through 5.

1. 9700 Series. (See IPL figure 1.)

CAUTION: TO PREVENT POSSIBILITY OF THREAD GALLING, THE REGULATOR BODY SHOULD NOT BE REMOVED FROM THE CYLINDER UNLESS THE CYLINDER IS DUE FOR HYDROSTATIC RETESTING OR CYLINDER CONTAMINATION IS SUSPECTED.

- A. Do not attempt to remove regulator (39 or 39A) from cylinder (45) until all external components have been removed from the regulator.
- B. Identification plate (38) and decal (43) are attached by an adhesive. Removal of these plates is not ordinarily required.
- C. Remove clamp (28) and harness (26).
- D. Unscrew and remove outlet assemblies (29).
- 2. 9800 Series. (See IPL figure 1.)
  - A. Remove clamp (28) and harness (26).
  - B. Do not attempt to remove regulator (39 or 39A) from cylinder (45) until all external components have been removed from the regulator.
  - C. Remove clamp (25) to remove bracket (24).
  - D. Unscrew nut of connector assembly (18). Unscrew connector assembly (18) from regulator (20).
  - E. Unscrew elbow assembly (19) and outlet assembly(s) (29) or plug (35) from regulator (39), then remove screws (22) to remove regulator (20).
  - F. Identification plate (38) and decal (43) are attached by an adhesive. Removal of these plates is not ordinarily required.

## SIMILE S

#### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL

- 3. 801242 Demand Regulator Assembly. (See IPL figure 2.)
  - A. Remove screws (4), and pull cover (9) off case (22). Removal of plates (5 or 7) is not normally required. If removal is necessary, drill out rivets (6 or 8).
  - B. Remove cord (11) and take disphragm assembly (10) off case (22).
  - C. Unthread screws (13) and remove deflector (12).
  - D. Remove screws (15) and washers (16 and 17). Pull valve assembly (14) out of case (22). Remove gasket (18).
  - E. Remove screen (21) from the inlet port of case (22).
  - F. Unscrew adapter (19 or 20) from the outlet port of case (22).

#### 4. Outlet Assemblies

- A. Part No. 5041. (See IPL figure 3.) Unthread screw (6). Remove screen (7), and pick cord (8) out of body (12). Remove screen (9), if necessary. Unscrew nut (3), and remove cover assembly (2). Slide cap (4) and washer (5) off case (18). Remove screw (11). Unscrew body (12) from case (18). Take spring (13), valve (14), and seat (15) out of case (18). Remove latch springs (16) and pins (17).
- B. Part No. 5009-00. (See IPL figure 4.) Remove cover (2). Remove screw (3), screen (4) and pick cord (5) out of stud (7). Unscrew stud (7) from receptacle (15). Remove valve (9), spring (10), and gasket (8). Thread flow port (11) out of stud (7). Remove gasket (14). Snap ring (12) out of flow port (11), and remove filter (13).
- C. Part No. 5507. (See IPL figure 5.) Remove screw (2) and screen (4). Remove cord (3) and screen (4) from body (12). Unscrew guide assembly (6). Remove washer (7) from guide assembly (6). Remove washers (8 and 9), seat (10), and spring (11) from body (12).
- D. Part No. 5052. (See IPL figure 6.) Remove screw (2). Remove screen (4), and pick cord (3) out of base (7). Take screen (4) and washer (5) out of base (7). Unthread base (7) from body (13). Remove gasket (8). Unthread seat (10). Remove gasket (11). Take retainer (12) and spring (9) out of body (13).

## SCOU

#### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL

- 5. 801160 Series Regulator Assembly. (See IPL figure 7.)
  - NOTE: The regulator should not be removed from the cylinder for disassembly. Disassembly of the regulator body from the cylinder should not be attempted until completion of the disassembly instructions listed below.
  - A. Unthread screws (33) and remove plate (32). Remove setscrew (34).
  - B. Unscrew and remove case (35 or 35A). Lift guide (36), spring (37), plate (38), ring (39), diaphragm (40), and plate (41) out of body (50 or 53).
  - C. Unscrew and remove holder (42). Remove seat (43 or 43A), pin (44), guide (45), and spring (46).
  - D. Unscrew and remove outlet assembly (25 through 28). Remove cap (25) from plug (28); then remove disc (26) and gasket (27) only if replacement of either is required. Remove washer (29) from body (50 or 53).
  - E. Remove on-off valve by unscrewing it from the regulator body. Use a wrench on the flats of the hexagonal portion of the valve body. Remove filter (18), if necessary.
  - F. Peel plate (5) off of handle (6). Remove nut (7) and washer (8). Pull handle (6) off stem assembly (13).
  - G. Remove washers (9 and 10).
  - H. Unscrew nut (11). Remove packing (12 or 12A) and seat (14).
  - J. Using stem assembly (13), back head assembly (15 or 15A) out of bushing (17).
  - K. Remove packing (16 or 16A).
  - L. Unscrew relief valve (31) from body (50 or 53).
  - M. Remove the sealing tape compound on threads of relief valve assembly (31).
  - N. Remove filler cap (19). Seat (20) is cemented to the cap. Unscrew and remove charging valve assembly (21) only if replacement is required. Then remove filters (22 and 23).

## THE

### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL

- P. Remove gauge (30) by using a thin wrench on the flats of the square boss at the rear of the case.
- R. Removal of regulator body (50 or 53) from the cylinder is not recommended and is not usually required. If removal is essential, carefully unthread the body from the cylinder using a strap wrench on the cylinder and a suitable wrench on the regulator.
- S. Remove tube (47) only if it is damaged. Remove plate (48) by removing screws (49) only if the plate is damaged.

## 500 TT

### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL

#### CLEANING

WARNING: DO NOT ALLOW CIL, GREASE, FLAMMABLE SOLVENTS, OR OTHER COM-BUSTIBLE MATERIALS TO COME IN CONTACT WITH PARTS THAT WILL BE EXPOSED TO PRESSURIZED OXYGEN. SUCH MATERIALS, AS WELL AS DUST, LINT, AND FINE METAL FILINGS ARE ALL POTENTIAL COMBUS-TIBLES WHICH MIGHT, WHEN EXPOSED TO OXYGEN UNDER PRESSURE, IGNITE AND RESULT IN AN EXPLOSION.

NOTE: Using the material listed in Table 401, perform the cleaning procedures outlined in the following paragraphs. Equivalent materials may be used.

MATERIAL	DESCRIPTION	MANUFACTURER*	REFER TO CLEANING PARAGRAPH
Di-Sanite	Di-Sanite	V44389	1.E
Phosphoric - Isopropyl	Phosphoric Acid Isopropyl Alchohol	V70829	1.C
Mixture	(50% of each by Vol)	NOTE: Purchased separately	
1,1,1 Trichloroethane	MIL-T-81533 . FED SPEC. 0-T-620	V71984	1.D, 1.H(1),(2),(3

Parts List, paragraph I.E for Vendor's Code

### List of Cleaning Materials Table 401

- 1. After inspecting cylinder in accordance with Check, perform the following cleaning procedure:
  - NOTE: This procedure will remove any organic impurities which are soluble in 1,1,1 Trichloroethane.
  - A. Wire brush the cylinder neck threads to remove sealing compounds or rust.
  - B. Shake out cylinder to remove any loose foreign matter.
  - C. Apply a solution (50% by volume of phosphoric acid isopropyl alcohol) by brush to the area wire brushed, exercising care to prevent excessive application from running into the cylinder.

## THE


#### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL

WARNING: USE 1,1,1 TRICHLOROETHANE IN A WELL VENTILATED AREA ONLY. AVOID PROLONGED OR REPEATED CONTACT WITH SKIN AND INHALATION OF TOXIC VAPORS.

- D. Utilizing a cleaning setup as illustrated in figure 401, place the cylinder, with neck down, in vertical position over the perforated tube (the diameter and length of the tube will be determined by the particular size of the cylinder being cleaned). Pump 1,1,1 Trichloroethane, slightly below its boiling point, through the tube thoroughly spraying the interior of the cylinder being cleaned for a period of three minutes. Remove cylinder from tube and allow complete drainage of 1,1,1 Trichloroethane into drain.
- E. After completion of step D, and using a cleaning setup similar to the setup illustrated in figure 401, pump a solution of Di-Sanite (8 ounces per each gallon of water), at a temperature of 180°F, through the tube, thoroughly spraying the interior of the cylinder being cleaned for a period of three to five minutes. Accomplishment of step E will neutralize any acid constituents and destroy odor.
- F. After completion of step E, and using a cleaning setup similar to the setup illustrated in figure 401, pump water (at city pressure) at 160°F, through the tube, thoroughly spraying the interior of the cylinder being cleaned for a period of two minutes to remove any traces of alkaline residue.
- G. After completion of step F, and using a cleaning setup similar to the setup illustrated in figure 401, dry the interior of the cylinder with forced air heated to a temperature of 212°F, for a period of three to five minutes.
- H. After completion of step G, and after the cylinder has cooled to room temperature, reinspect the cylinder in accordance with Check.
  - NOTE: The cleaning process used should be checked initially and periodically as follows:
  - (1) Pour 50cc of anhydrous, chemically pure, 1,1,1 Trichloroethane into the processed cylinder. Cap and shake well for one to two minutes.
  - (2) Remove cap and pour flushings into a clean Erlenmeyer flask. Distill the 1,1,1 Trichloroethane in a water bath. After the 1,1,1 Trichloroethane has been distilled, examine residue in flask. If oil marks are visible, check cleaning solutions, implements and pressure.

### 50DU

#### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL



Cleaning Setup Figure 401

> 35-31-55 Page 403 Mar 1/83

### TIME

#### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL

- (3) After completion of steps (a) and (b), and using a cleaning setup similar to the setup illustrated in figure 401, clear all traces of 1,1,1 Trichloreothane from the interior of the cylinder by blowing with dry, clean, oil-free air.
- After inspecting the valve assembly in accordance with Check, perform the following cleaning procedure.

WARNING: DO NOT ALLOW OIL, GREASE, FLAMMABLE SOLVENTS, OR OTHER COMBUSTIBLE MATERIALS TO COME IN CONTACT WITH PARTS THAT WILL BE EXPOSED TO PRESSURIZED OXYGEN. SUCH MATERIALS, AS WELL AS DUST, LINT, AND FINE METAL FILINGS ARE ALL POTENTIAL COMBUSTIBLES WHICH MIGHT, WHEN EXPOSED TO OXYGEN UNDER PRESSURE, IGNITE AND RESULT IN AN EXPLOSION.

A. Remove dirt and foreign particles from equipment by wiping with a clean lint-free cloth, or by blowing with clean oil-free air or nitrogen.

USE 1,1,1 TRICHLOROETHANE IN A WELL VENTILATED AREA ONLY. AVOID PROLONGED OR REPEATED CONTACT WITH SKIN AND INHALATION OF TOXIC VAPORS.

- B. Metal parts which come in contact with oxygen and have become contaminated with grease can be cleaned by using a vapor degreasing method with 1,1,1 Trichloroethane. Blow clean and dry with a stream of clean dry, oil-free air.
- C. Non-metallic parts such as silicone and rubber components may be cleaned by using an ultrasonic detergent and water cleaning system. Rinse parts in clean water and dry thoroughly before reassembly.

# ट्रागा

#### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL

#### CHECK

- Inspect exterior of cylinder for indications of abuse, dents and bulges.
- Inspect neck of cylinders for cracks and distortion or damaged threads.
- Inspect all cylinders for peeling external paint and obscure markings.
- 4. Inspect all high pressure cylinders for last date of hydrostatic test and type. If hydrostatic testing is required, tests shall be in accordance with prescribed procedures by facilities holding a current, valid DOT Approval.

NOTE: DOT Type 3HT cylinders require hydrostatic retesting every 3 years. DOT type 3A and 3AA cylinders require hydrostatic retesting every 5 years. Under certain usage conditions, DOT type 3A and 3AA cylinders may be retested at 10 year intervals. Refer to the current tariff of the "HAZARDOUS MATERIAL REGULATIONS OF THE DEPARTMENT OF TRANSPORTATION" (49 CFR 170) paragraph 173.34 (e) (15) for eligibility requirements.

NOTE: For Cylinder Inspection and Hydrostatic Retest, the use of Compressed Gas Association (CGA) pamphlets C-1, C-5, C-6, C-8 are recommended. These are available from:

CGA, INC. 1235 Jefferson Davis Highway Arlington, VA 22202

- Inspect the interior for defects which might render the cylinder unsafe.
- 6. Inspect the interior of cylinders for rust spots, improper parkerizing, or surface blemishes.
- 7. Inspect valves and/or regulator for cracks, nicks, dents, or burrs which might cause malfunction.
- 8. Inspect valve seats for scoring.
- 9. Inspect all threads of valves and/or regulators for damage.
- 10. Inspect overall condition of all components.

### ध्या

#### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL

#### REPAIR

1. Using the material listed in Table 601, perform the repair procedures outlined in the following paragraphs.

NOTE: Equivalent materials may be used.

MATERIAL	DESCRIPTION	MANUFACTURER*	REFER TO REPAIR PARAGRAPH
Chromic Acid	Chromic Acid	V72658	5.E
Phosphoric Acid	Phosphoric Acid	v70829	5.C 5.E
Zinc Phosphate Coating	Zn PO4	V44389	5.C

\*Refer to Illustrated Parts List, paragraph 1.E for Vendor's Code

#### List of Consumable Materials for Repair Table 601

- Repair of parts, other than removing burrs, is not recommended. If a part is in need of repair, discard it and replace the part.
- Replace all gaskets, washers, packings, diaphragms, nonmetallic valve seats and filter screens at each overhaul.
- 4. Replace cylinders that show signs of abuse, dents, bulges, cracks, distortion, damaged threads, and/or defects which might render the cylinder unsafe (refer to Check, steps 3, 4, 5 and 7).
  - NOTE: DOT 3HT Type cylinders shall be discarded at the end of twenty-four years from original test date or 4,380 pressurizations, whichever occurs first.
- 5. Cylinders that require interior protective treatment may be reparkerized as follows: (Refer to Check, step 8.)
  - A. Sandblast cylinders internally and externally using fine grit shot.
  - B. Rinse cylinder in clean water.

# MAR

# 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL

C. Apply a phosphate coating to the interior of the cylinder either by dipping or spraying. For dip-coating, a three minute minimum dip is recommended; for spray-coating, one minute minimum is recommended.

NOTE: The balanced aqueous solution of phosphoric acid, phosphates, and accelerating agents produces a uniform water insoluble crystalline coating varying from gray to black in color.

- D. Rinse cylinder in clean water.
- E. Rinse cylinder in hot chromic acid (140 to 210°F),

NOTE: The pH of the chromic acid rinse will be maintained between 2 and 4 by the addition of flake chromic acid of a mixture of chromic and phosphoric acids.

F. Dry the cylinder by using warm air or a drying oven.

NOTE: For maximum corrosion resistance, coating weights of 400 mg/sq. ft. are usually adequate. This coating weight may be reduced to 200 mg/sq. ft. if an activator (titanium salts) is used. The coating weight may be deceptive if loosely adherent deposits are obtained, since loosely adherent deposits give inferior performance. Finely crystalling zinc phosphate coatings provide the best corrosion resistance.

- 6. If the exterior finish is removed, it must be recoated with 1000 mg/sq. ft. min. phosphate, and primed per MIL-P-8585A, color Y.
- Remark and/or repaint cylinders in accordance with information outlined in figures 2 and 3.

### IIII

#### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL

#### ASSEMBLY

NOTE: Table 701 lists the consumable materials necessary for assembly. Equivalent materials may be used except for oxygen lubricant.

MATERIAL	DESCRIPTION	MANUFACTURER*	REFER TO ASSEMBLY PARAGRAPH
Permacel Thread Sealant Tape	Permacel No. 412	V99742	2.A, 2.B, 2.C, 2.E, 2.F, 4.B, 4.C
Insa-Lute Adhesive	Insa-Lute Adhesive No. 1	V80703	2.0
Loctite Sealant	Loctite, Grade C	V05972	2.M
Oxygen Lubricant	Krytox 240AC	V18873	2.G, 2.H, 2.J, 2.L, 2.N
Oxygen	MIL-0-27210, Type I	V07098	3.C

List of Consumable Materials for Assembly Table 701

#### 1. Outlet Assemblies

- A. Part No. 5052. (See IPL figure 6.) Place retainer (12) and spring (9) in body (13). Place gasket (11) on seat (10), and thread base (7) onto the body. Install gasket (8) on body (13). Install washer (5) and screen (4) in base (7). Pack cord (3) into the opening of base (7). Install screen (4) and screw (2).
- B. Part No. 5507. (See IPL figure 5.) Place spring (11), seat (10) and washers (8 and 9) in body (12). Place washer (7) in guide assembly (6), and screw guide assembly (6) into body (12). Place screen (4) into body (12) and cord (3) into the body. Install screen (4) and screw (2).

# mae

#### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL

- C. Part No. 5009-00. (See IPL figure 4.) Place filter (13) on flow port (11), and hold in place by installing ring (12). Install gasket (14) in stud (7), and thread flow port (11) into stud (7). Install gasket (8), valve (9), and spring (10) into receptacle (15). Thread stud (7) into receptacle (15). Pack cord (5) into stud (7). Thread screw (3) into stud (7) after installing screen (4). Slide cap (2) in place on receptacle (15).
- D. Part No. 5041. (See IPL figure 3.) Position pins (17) on case (18), and hook springs (16) over the grooved ends of the pins. Install seat (15), valve (14), and spring (13) in case (18). Screw body (12) into case (18). Thread setscrew (11) into case (18). Slide washer (5) and cap (4) into case (18). Assemble nut (3) and cover assembly (2), then thread nut (3) onto case (18). Place screen (9) into the opening of body (12). Pack cord (8) into the opening and install screen (7) and screw (6).
- 2. 801160 Series Regulator Assemblies. (See IPL figure 7.)

NOTE: Body (50 or 53) must be assembled to a cylinder before assembly of the regulator.

- A. If body (50 or 53) was removed from a cylinder, make sure tube (47) is pressed into the body, then secure the cylinder in a strap wrench. Wrap 1-1/2 turns of thread sealing tape to body (50 or 53) in the direction of the thread spiral, beginning with the first thread. In no case shall the tape extend beyond the first thread. Trim off excess tape. Tighten body (50 or 53) into cylinder using a suitable wrench. Torque body per Table 801.
- B. Wrap 1-1/2 turns of thread sealing tape to gauge (30) in the direction of the thread spiral, beginning with the first thread. In no case shall the tape extend beyond the first thread. Trim off excess tape. Thread gauge (30) into body (50 or 53). Use a thin wrench on the gauge pipe connection square. Torque per Table 801.
- C. Wrap 1-1/2 turns of thread sealing tape to valve assembly (21) body in the direction of the thread spiral, beginning with the first thread. In no case shall the tape extend beyond the first thread. Trim off excess tape. Assemble valve assembly (21) to body (50 or 53) after installing filters (22) and (23). Torque per Table 801.

# SMIT

- D. If necessary, cement seat (20) to cap (19) using Insamlute adhesive. Coat rough side of seat (20) and inside of cap (19) with adhesive, then join and allow parts to air dry. Thread cap (19) with seat (20) onto valve assembly (21) after adhesive has thoroughly dried.
- E. Wrap 1-1/2 turns of thread sealing tape to valve assembly (31) in the direction of the thread spiral, beginning with the first thread. In no case shall the tape extend beyond the first thread. Trim off excess tape. Install the valve assembly in body (50 or 53). Do not tighten valve at this time. It is necessary to remove relief valve when testing regulator assembly. When valve assembly is finally installed, torque per Table 801.
- F. Wrap 1-1/2 turns of thread sealing tape to appropriate outlet assembly in the direction of the thread spiral, beginning with the first thread. In no case shall the tape extend beyond the first thread. Trim off excess tape. Install the appropriate outlet assembly at this time. Torque per Table 801.
- G. Position filter (18) in opening of body (50 or 53). Apply a wipe coat of oxygen lubricant to packing (16 or 16A), then install bushing (17) until it bottoms on body (50 or 53). Observe that the filter is not wrinkled or twisted.
- H. Apply a wipe coat of oxygen lubricant to stem of stem assembly (13).
- J. Apply a wipe coat of oxygen lubricant to threaded area of head assembly (15 or 15A) and install head assembly (15 or 15A) in bushing (17), using stem assembly (13) to thread head assembly (15 or 15A) into bushing (17).
- K. Install seat (14) on stem assembly (13) and push seat (14) into bushing (17).
- L. Apply a wipe coat of oxygen lubricant to packing (12 or 12A), then assemble packing (12 or 12A) on nut (11) and thread nut (11) into bushing (17).
- M. Place washers (9 and 10) on stem assembly (13). Assemble handle (6) to stem assembly (13) with washer (8) and nut (7), after applying Loctite to the exposed threads of the stem assembly. Press plate (5) on handle (6).

### III

#### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL

- N. Position gasket (27) and disc (26) in cap (25) and apply a wipe coat of oxygen lubricant to exposed surface of gasket (27).

  Insert washer (29) in body (50 or 53) and torque cap (25) to plug (28) per Table 801. Torque outlet assembly (25 through 28) to body (50 or 53) per Table 801.
- P. Place spring (46) and guide (45) in body (50 or 53).
- R. Inspect the center hole of seat (43 or 43A) and the seating area of pin (44) with a magnifying glass or microscope. These areas must be smooth and clean without cracks, nicks, or burrs. Insert pin (44) in seat (43 or 43A) and place the assembly into body (50 or 53).
- S. Inspect the thread of holder (42) with a magnifying glass or microscope. Make sure that the first thread does not have a sharp leading edge and that the entire thread is free of burrs and rough edges. Torque holder (42) into body (50 or 53) per Table 801. Over-torquing may result in damage to seat (43).
- T. Place plate (41), diaphragm (40), three rings (39), plate (38), spring (37) and guide (36) in position in body (50 or 53).
  - NOTE: Three rings (39) are normally required to properly seal diaphragm (40) while engaging a maximum number of threads of case (35 or 35A). The number of rings (39) may be altered if necessary to accomplish this.
- U. Thread case (35 or 35A) onto body (50 or 53). Tighten case (35) until it bottoms on body (50 or 53). Install setscrew (34) loosely.

NOTE: Do not install plate (32) and screws (33) until completion of Testing.

- 3. Part No. 801242 Demand Regulator Assembly. (See IPL figure 2.)
  - A. Thread adapter (19 or 20) onto the outlet port of case (22).
  - B. Install screen (21) in the inlet port of case (22).
  - C. Install gasket (18) and attach valve assembly (14) to case (22), using washers (16 and 17) and screws (15). Connect a supply of oxygen to the inlet port, and adjust oxygen pressure to 85 psi. Cover sealing area of valve assembly (14) with a small amount of clean water. Bubbles indicate leakage which must be corrected. After successful completion of this test, remove the oxygen source, dry the regulator by blowing with clean, dry, waterpumped air, and continue reassembly.

### HUE

#### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL

- D. Attach deflector (12) to case (22) with screws (13). Clearance must be noted between the demand valve stem and the deflector. Lack of clearance will cause the demand valve to open.
- E. Install diaphragm assembly (10) over case (22) so that diaphragm edge extends to edge of machined surface beyond groove. Wrap cord (11) around diaphragm at groove in case four full turns and tie securely. The diaphragm must lay smoothly without wrinkles or folds. Apply clear lacquer over knot tied in cord (11).
- F. Rivet plates (5 and 7) to cover (9) with rivets (6 and 8), then assemble cover assembly to case (22) with screws (4).
- 4. 9800 Series (See IPL figure 1.)
  - NOTE: All components of the 9800 Series must be completely tested prior to assembly. Instructions for the testing of components are listed in Testing.
  - A. With regulator (39 or 39A) assembled to cylinder (45), place loop of harness (26) over the regulator onto neck of cylinder (45).
  - B. Wrap 1-1/2 turns of thread sealing tape to elbow assembly (19) in the direction of the thread spiral, beginning with the first thread. In no case shall the tape extend beyond the first thread. Trim off excess tape. Thread the elbow assembly into regulator (39 or 39A).
  - C. Wrap 1-1/2 turns of thread sealing tape to connector assembly (18) in the direction of the thread spiral, beginning with the first thread. In no case shall the tape extend beyond the first thread. Trim off excess tape. Thread the connector assembly into regulator (20).
  - D. Assemble bracket (24) to regulator (20) with screws (22), then align this unit on the cylinder and unite elbow assembly (19) to connector assembly (18).
  - E. Connect bracket (24) to cylinder by installing clamp (25), then secure loose end of harness (26) to the cylinder with clamp (28).
  - F. If necessary, attach identification plate (38) to regulator. Affix decal (43) to cylinder if necessary.

NOTE: Outlet assemblies (29) are normally assembled to regulator (39 or 39A) when regulator is reassembled.

# SOUT

#### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL

#### 5. 9700 Series (See IPL figure 1.)

NOTE: All components of the 9700 Series must be completely tested prior to final assembly. See Testing for testing instructions.

- A. With regulator (39 or 39A) assembled to cylinder (44), place loop of harness (26) over regulator (39 or 39A) onto neck of cylinder (44). Secure Loose end of harness (26) to cylinder with clamp (28).
- B. If necessary, attach identification plate (38) to regulator. Affix decal (43) to cylinder if necessary.

NOTE: Outlet assemblies (29) are normally assembled to regulator (39 or 39A) when regulator is reassembled.

#### 6. Storage Instructions

- A. Make sure on-off valve assembly is closed prior to placing the assembly in storage. '
- B. Plug all openings with suitable dust caps and wrap the unit in a clean plastic bag to prevent dust accumulation. Do not use preservative coatings of any type.
- C. Make sure that cylinder pressure is always a minimum of 200 psi.

### aou

#### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL

#### FITS AND CLEARANCES

1. Table 801 presents the torque values necessary to assemble the unit.

UNIT	TORQUE (Newton meters)
Outlet Assemblies (28, IPL figure 1)	*40 to 80 Inch Pounds (4,5 - 9,0)
Charging Valve Assembly (21, IPL figure 7)	*60 to 250 Inch Pounds (6,8 - 28,3)
Cap (25, IPL figure 7)	260 Inch Pounds (29,4)
Safety Outlet Assembly (25 through 28, IPL figure 7)	150 Inch Pounds (16,9)
Gauge (30, IPL figure 7)	1 40 Inch Pounds (4,5)
Relief Valve (31, IPL figure 7)	25 to 50 Inch Pounds (2,8 - 5,6)
Seat Holder (42, IPL figure 7)	50 Inch Pounds (5,6) 2 100 Inch Pounds (11,3)
Regulator Body (50 or 53, IPL figure 7)	100 Foot Pounds (136)
*Torque to minimum values. If leakage but do not exceed the maximum.	occurs, retorque to a higher value
Determined by orientation.  100 Inch Pounds for 801160-01 & 801150 - 100 Inch Pounds for 801160-03 & 801150 - 100 E 801160 - 1	

Assembly Torque Values
Table 801

### SWII T

#### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL

#### SPECIAL TOOLS, FIXTURES AND EQUIPMENT

 There are no special tools required to overhaul the portable cylinder assemblies.

# TIME

#### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL

#### ILLUSTRATED PARTS LIST

- This illustrated Parts List lists and describes the parts of the 9700 series and 9800 series, Portable Cylinder Assemblies.
  - A. The Illustrated Parts List consists of seven parts listings and seven completely indexed drawings. The cylinder assemblies are followed immediately by their component parts, properly indented thereunder, to show their relationship to the units.
  - B. The quantities listed in the "UNITS PER ASSY" column are, in the case of assemblies, the total quantity used per cylinder assembly at the location indicated, while the component parts indented under the assemblies are the quantity used per assembly. The quantities specified, therefore, are not necessarily the total used per cylinder assembly. See the Numerical Index for the total quantity used per cylinder assembly. It should be noted that the index quantity only reflects the use of one or two outlet assemblies. If less than one outlet is present, quantities must be adjusted accordingly.
  - C. The part numbers listed in the "PART NUMBER" column are Scott Aviation part numbers except standard parts, which are listed by "MS" and "AN" part numbers, and vendor items which are listed by vendor part numbers.
  - D. When the quantity of a part is to be selected as required, the abbreviation AR will appear in the "UNITS PER ASSY" column.
  - E. A six place code following the description of a part indicates the manufacturer of that part. Standard parts and parts carried under Scott part numbers have no six place vendor code. The following list contains the codes, and names and addresses of manufacturers supplying items or articles for the breathing unit. This listing includes the vendor codes presented in Tables 101, 401, 601 and 701.

#### VENDOR'S CODE

V05972

American Sealants Co.
Hartford, Connecticut

V07098

Linde Division of Union Carbide
Tonawanda, New York

V18034

Nupro
Willoughby, Ohio

### III

#### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH I'PL

#### VENDOR'S CODE

NAME AND ADDRESS CODE Owens-Corning Fiberglass Corp. V21343 Huntington, Pennsylvania V44389 Oakite Products, Inc. Berkley Heights, New Jersey V49315 Puritan Equipment, Inc. Lenexa, Kansas E.I. DuPont De Nemours & Co., Inc. V18873 Petroleum Chemicals Division Wilmington, Delaware J.T. Baker Chemical Co. V70829 N. Phillipsburg, New Jersey Hooker Chemical Corp. V71984 Niagara Falls, New York Allied Chemical Corp. V72658 Industrial Chemicals Division Morristown, New Jersey Sauereisen Cements Co. V80703

V99742

New Brunswick, New Jersey

Pittsburgh, Pennsylvania

Johnson and Johnson Inc.

Permacel Division

### mm

#### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL

F. The following effect codes have been assigned to the items contained in IPL figure 1.


PART NO.	EFFECT CODE
9700 SERIES & 9800 SERIES	Select applicable codes from list- ings in figure 1001.
Select effect code from figure 1001	
Used on 9800 Series	2
Used on 9800 Series with	3
6084-2 cylinders	
Used on 9700 and 9800	4
Series with 6084-1 and	
6084-2 cylinders.	
Used on 9700 Series	<
	6
Used on 9800 Series when	0
no constant flow outlets	
required.	-
Used on 9700 and 9800 Series	
with 6084-20 cylinders	
Used on 9700 and 9800 Series	8
when two constant flow	
outlets required.	
Used on 9700 Series with	9
6084-1 cylinders.	
Used on 9700 Series with	16
6084-2 cylinders	

# SUU

- 2. How to use this Illustrated Parts List
  - (1) If neither the part number nor the nomenclature is known, the part can be found by comparison with the exploded view illustration. When located on the illustration, the item number will refer to the line in the Parts List with the part number and the nomenclature.
  - (2) If the part number is known, refer to the Numerical Index and find the part number. Opposite the part number is the figure and item number which refers to the Parts List. Proper nomenclature is opposite the item number on the Parts List page.

# SUUT

#### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL



Effect Code Figure 1001

35-31-55

	AIRLINE			TTL
PART NUMBER	PART NUMBER	FIGURE	ITEM	REQ
A1120B		S	18	1
A1126		2	12	
A1215-1		2	11	
AN345C10	j	7	7	1 1
ANS15-4-3		2	4	3
AN515-4-4		2	15	2
AN936A4		2	16	2
AN960C10L	}	7	8	1
EC9-SU	1	3	8	AR
	ļ	4	5	
		5	3	ì
	Į .	6	3	1
MS20470A2-2		2	6	4
10001296	•	1	24	1
10001493		4	11	1
10001494	1	4	7	1 1
10002408		7	48	1 1
10002538		1 1	-37	1
10002539		1 1	38	1 1
10002542		1	-42	1 1
10002543		- 1	43	1
10003202	1	1 1	-36	1 1
10003209		7	-51	1
10003319	ł .	7	-52	1
10003566	1	1	-34A	1 1
13160		1	25	2
13374-00		1 2	28 10	١.,
18037-01		7	16	1 ;
18341		1 2	49	1 5
210331	İ		6	1 4
22427-1	<b>{</b>	1 5	1 2	1 4
22445-1		1 5	6	1 4
23274-05		-		
23393-1	1	1 5	17	
23394-01		7	111	
	{			
24823			45	
24825			15	
26565		1 4	25	
26567	1	1 -	28	1 1
2661-03	j .	1 -	30	1 1
27170-01		1 1	53	
27170-02	Ł.	1 7	-54	1 7

# STUTE

PART NUMBER		AIRLINE			TTL
29551 29552 29553-1 29553-1 3	PART NUMBER	PART NUMBER	FIGURE	ITEM	REQ
29552 29553-1 29554 29555 3 16 29555 3 16 29557 3 17 29558-1 29556 3 17 29558-1 3 2 1 29567 3 11 1 -340 37008-01 1 -340 37008-01			3	1	
29553-1       3       15       1         29554       3       18       1         29555       3       17       2         29556       3       17       2         29557       3       3       1         29567       3       1       1         36728-01       1       -340       1         37008-01       7       34       1         5002       7       45       1         5003       7       35       1         5005-01       7       35A       1         5005-03       7       35A       1         5009-00       1       29       2         5013       4       4       2         5013       4       4       2         5014       4       2       4         5014-1       3       6       1         5014       4       3       1         5014-1       3       6       1         5018       7       19       1         5023       7       46       1         5028       7       44       1 <tr< td=""><td></td><td></td><td>3</td><td></td><td></td></tr<>			3		
29554       3       18       1         29555       3       16       2         29557       3       3       1         29557       3       3       1         29567       3       11       1         36728-01       1       -340       1         37008-01       7       34       1         5002       7       45       1         5003       7       37       1         5005-03       7       35A       1         5009-00       1       29       2         5009-01       4       -6       1         5013-1       3       7       2         5014       4       3       1         5014-1       3       6       4         5016       7       19       1         5018       7       47       1         5028       7       44       1         5029       7       43       1         5030-1       7       42       1         5031       7       42       1         5032-1       7       40       1 </td <td></td> <td></td> <td>3</td> <td></td> <td></td>			3		
29555     3     16     2       29556     3     17     2       29557     3     3     1       29557     3     3     1       29567     3     11     1       36728-01     1     -340     1       37008-01     7     34     1       5002     7     45     1       5003     7     37     1       5005-01     7     35     1       5005-03     7     35A     1       5009-00     1     29     2       1     -30     -1     -30       4     -1     -30     -1       5013     4     4     2       5013-1     3     7     2       5014-1     3     6     4       5018     7     19     1       5028     7     46     1       5028     7     44     1       5029     7     43     1       5030-1     7     42     1       5031     7     40     1			3		
29556       3       17       2         29557       3       3       1         29558-1       3       2       1         29567       3       11       1         36728-01       1       -340       1         37008-01       7       34       1         5002       7       45       1         5003       7       37       1         5005-03       7       35A       1         5005-03       7       35A       1         5009-00       1       29       2         1       -30       4       -1         5013       4       4       2         5013-1       3       7       2         5014       4       3       1         5014-1       3       6       1         5014       4       3       1         5014-1       3       6       1         5018       7       19       1         5023       7       20       1         5024       7       44       1         5025       7       44       1			3		2
29557 2958-1 29567 3			2		2
29558-1       3       2       1         29567       3       11       1         36728-01       1       -340       1         37008-01       7       34       1         5002       7       45       1         5003       7       37       1         5005-01       7       35       1         5005-03       7       35A       1         5009-00       1       29       2         1       -30       4       -1         5009-01       4       -6       1         5013       4       4       2         5013       4       4       2         5014       4       3       1         5014       4       3       1         5014       4       3       1         5014       4       3       1         5014       5       2       2         5018       7       19       1         5023       7       20       1         5028       7       43       1         5030-1       7       42       1			3	7	4
29567 36728-01  3			3	2	
36728-01       1       -340       1         37008-01       7       34       1         5002       7       45       1         5003       7       37       1         5005-01       7       35A       1         5005-03       7       35A       1         5009-00       1       29       2         1       -30       4       -1         5009-01       4       -6       1         5013       4       6       4         5013       3       7       2         5014       4       3       1         5014-1       3       6       1         5014-1       3       6       1         5018       7       19       1         5018       7       47       1         5018       7       47       1         5018       7       47       1         5023       7       46       1         5029       7       43       1         5030-1       7       42       1         5031       7       41       1	I I		3		
37008-01       7       34       1         5002       7       34       1         5003       7       37       1         5005-01       7       35       1         5005-03       7       35A       1         5009-00       1       29       2         1       -30       4       -1         5009-01       4       -6       1         5013       4       4       2         5013-1       3       7       2         5014       4       3       1         5014-1       3       6       1         5018       7       19       1         5018       7       47       1         5023       7       46       1         5029       7       43       1         5030-1       7       42       1         5031       7       41       1         5032-1       7       40       1			3		
37008-01       7       34       1         5002       7       45       1         5003       7       37       1         5005-01       7       35       1         5005-03       7       35A       1         5009-00       1       29       2         1       -30       4       -1         5009-01       4       -6       1         5013       4       4       2         5013-1       3       7       2         5014-1       3       6       4         5014-1       3       6       1         5018       7       19       1         5018       7       47       1         5023       7       46       1         5029       7       44       1         5030-1       7       42       1         5031       7       41       1         5032-1       7       40       1	36728-01		1		1
5002       7       45       1         5003       7       37       1         5005-01       7       35       1         5005-03       7       35A       1         5009-00       1       29       2         1       -30       4       -1         4       -6       1       -30         4       -1       -6       1         5013       4       4       2         5014       4       3       1         5014-1       3       6       1         5016       7       19       1         5018       7       47       1         5023       7       20       1         5028       7       46       1         5029       7       43       1         5030-1       7       42       1         5031       7       41       1         5032-1       7       40       1			1 1		
5003       7       37       1         5005-01       7       35       1         5005-03       7       35A       1         5009-00       1       29       2         1       -30       -1       -6       1         5009-01       4       -6       1       -6       1         5013       4       4       2       -6       4       2         5013-1       3       7       2       2       -7       4       3       1       -7       -7       4       3       1       -7	1				
5005-01       7       35       1         5005-03       7       35A       1         5009-00       1       29       2         1       -30       4       -1         5009-01       4       -6       1         5013       4       4       2         5013-1       3       7       2         5014       4       3       1         5014-1       3       6       1         5018       7       19       1         5018       7       47       1         5027       7       46       1         5028       7       44       1         5029       7       43       1         5030-1       7       42       1         5031       7       41       1         5032-1       7       40       1			_		
5005-03       7       35A       1         5009-00       1       29       2         1       -30       4       -1         5009-01       4       -6       1         5013       4       4       2         5013-1       3       7       2         5014       4       3       1         5014-1       3       6       1         5018       7       19       1         5023       7       20       1         5027       7       46       1         5028       7       44       1         5030-1       7       42       1         5031       7       40       1					
5009-00       1       29       2         5009-01       4       -6       1         5013       4       4       2         5013-1       3       7       2         5014       4       3       1         5014-1       3       6       1         5016       7       19       1         5018       7       47       1         5023       7       20       1         5027       7       46       1         5028       7       44       1         5030-1       7       42       1         5031       7       40       1			4		
5009-01       4       -1         5013       4       -6       1         5013-1       3       7       2         5014-1       3       7       2         5016-1       3       6       1         5018-1       7       19       1         5023-1       7       46       1         5030-1       7       44       1         5031-1       7       42       1         5031-1       7       41       1         5032-1       7       40       1					
5009-01       4       -1         5013       4       4         5013-1       3       7       2         5014-1       3       9       5         5016-1       3       6       1         5018-1       7       19       1         5023-1       7       20       1         5029-1       7       44       1         5031-1       7       42       1         5031-1       7       41       1         5032-1       7       40       1	5009-00		]		2
5009-01       4       -6       1         5013       4       4       2         5013-1       3       7       2         5014       4       3       1         5014-1       3       6       1         5016       7       19       1         5018       7       47       1         5023       7       20       1         5027       7       46       1         5028       7       44       1         5029       7       43       1         5030-1       7       42       1         5031       7       41       1         5032-1       7       40       1			]		
5013       4       4       2         5013-1       3       7       2         5014       4       3       1         5014-1       3       6       1         5016       7       19       1         5018       7       47       1         5023       7       20       1         5027       7       46       1         5028       7       44       1         5029       7       43       1         5030-1       7       42       1         5031       7       41       1         5032-1       7       40       1			4	1	
5013-1       3       7       2         5014       4       3       1         5014-1       3       6       1         5016       7       19       1         5018       7       47       1         5023       7       20       1         5028       7       44       1         5029       7       43       1         5030-1       7       42       1         5031       7       41       1         5032-1       7       40       1	•		4	1	1
5013-1       3       7       2         5014       4       3       1         5014-1       3       6       1         5016       7       19       1         5018       7       47       1         5023       7       20       1         5027       7       46       1         5028       7       44       1         5029       7       43       1         5030-1       7       42       1         5031       7       41       1         5032-1       7       40       1	5013				2
5014       3       9         5014-1       4       3       1         5016-1       3       6       1         5018-1       7       19       1         5023-1       7       47       1         5028-1       7       46       1         5029-1       7       44       1         5031-1       7       41       1         5032-1       7       40       1			0	4	
5014       4       3       1         5014-1       3       6       2         5016       7       19       1         5018       7       47       1         5023       7       20       1         5027       7       46       1         5028       7       44       1         5029       7       43       1         5030-1       7       42       1         5031       7       41       1         5032-1       7       40       1	5013-1		3		2
5014-1       3       6       2         5016       7       19       1         5018       7       47       1         5023       7       20       1         5027       7       46       1         5028       7       44       1         5029       7       43       1         5030-1       7       42       1         5031       7       41       1         5032-1       7       40       1			5	,	
5014-1       3       6       2         5016       7       19       1         5018       7       47       1         5023       7       20       1         5027       7       46       1         5028       7       44       1         5029       7       43       1         5030-1       7       42       1         5031       7       41       1         5032-1       7       40       1			2	4	
5014-1     3     6     1       5016     7     19     1       5018     7     47     1       5023     7     20     1       5027     7     46     1       5028     7     44     1       5029     7     43     1       5030-1     7     42     1       5031     7     41     1       5032-1     7     40     1	5014		<b>1</b>	3	1
5016       7       19       1         5018       7       47       1         5023       7       20       1         5027       7       46       1         5028       7       44       1         5029       7       43       1         5030-1       7       42       1         5031       7       41       1         5032-1       7       40       1	5044 4		1 =		4
5016     7     19     1       5018     7     47     1       5023     7     20     1       5027     7     46     1       5028     7     44     1       5029     7     43     1       5030-1     7     42     1       5031     7     41     1       5032-1     7     40     1	2U14*1		3	1	'
5018     7     47     1       5023     7     20     1       5027     7     46     1       5028     7     44     1       5029     7     43     1       5030-1     7     42     1       5031     7     41     1       5032-1     7     40     1	5014		7	_	4
5023     7     20     1       5027     7     46     1       5028     7     44     1       5029     7     43     1       5030-1     7     42     1       5031     7     41     1       5032-1     7     40     1			7		
5027     7     46     1       5028     7     44     1       5029     7     43     1       5030-1     7     42     1       5031     7     41     1       5032-1     7     40     1			7		3
5028       7       44       1         5029       7       43       1         5030-1       7       42       1         5031       7       41       1         5032-1       7       40       1			7		1
5029     7     43     1       5030-1     7     42     1       5031     7     41     1       5032-1     7     40     1			7		1
5030-1     7     42     1       5031     7     41     1       5032-1     7     40     1			7		i
5031     7     41     1       5032-1     7     40     1			7		1
5032-1 7 40 1			7		1
			7		1
7 38 1			7		3
	5034		7	38	1
					-

SWII

	AIRLINE			TTL
PART NUMBER	PART NUMBER	FIGURE	TTEM	REQ
5041-00		1	-31	2
		1	-32	
		3	-1	j
5041-1		3	-10	1
504?-1		3	4	1
5042-2		3	5	1 1
5043-14		7	31	1
5052-00		1	-348	1
		6	-1	
5052-2		6	-6	1
5053-07		7	58	1 4
5056		7	32	1
5058		, i	1 2	
5065-2		4	12	4
		4		
5045-3		7	14	
5065-4		7	13	1 1
5065-6		7	10	
5065-8		7	8	!!
5067-1		6	7	1
5067-2		6	8	1 1
5067-3		6	13	1
5067-4		6	9	1
5067-5		6	12	] 1
5067-6		6	11	1
5067-7		6	10	1
5093-01		7	21	1
520058		5	10	1
5507-00		1	-33	2
		1	-34	}
		5	-1	1
5511		7	10	2
5513		7	13	1 1
5517		. 7	14	1 1
5518		7	15	Ιi
5520-15		7	-4	1 1
5520-16		7	-4A	
5522		7	18	1 4
5533		5	-5	
5533 <del>-</del> 1		é	12	1 4
55620-01		2	•	
		7	12A	
55620-02			16A	
5601			19	
5602		T	18	] 1


# SIDIL

	AIRLINE			TTL
PART NUMBER	PART NUMBER	FIGURE	ITEM	REQ
5603		2	19	1
5606		2	20	1
5607-3		2	22	3
59447-00		4	2	1
59553-00		7	33	2
59598-00		7	12	1
59602-00		1	22	4
6050-1		2	9	1
6050D		2	-3	1
6055E		2	14	1
6066		2	17	2
6084-1		1	-44	1
6084-20		1 1	45	1
614010		5	9	1
6370		7	29	1
6375-05		2	5	i
6378		2	7	
6555		7	27	1
6812		2	21	1
6818-00		1 1	-35A	1
6818-1			-35	1
7171-00		7	26	1 1
801160-00		4	39	1
001100 00		7	-1	,
801180-01		1	-40	1
1		7	-2	i i
801160-02		1 1	-41	1
001100-02		7	-3	•
801160-03			39A	1
001100-03		1 1	-40A	'
		7	-2A	
801160-04			-41A	4
001100 04		7	-3A	•
801242-01			20	1
001242 01			-1	•
801242-02		1 1	-21	1
001242-02			-2	•
801421-00		7	-24	1
801658-00			-27	1
801660-00			26	4
802883-01		7	15A	4
803129 <del>-</del> 01		7	43A	
832100			7	4
832402			8	1
036402			0	

### MILE

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	TTL
833012		5	11	1
8384		7	23	1
8385		7	22	2
8561		7	36	1
9036		2	13	2
9700 SERIES		1	-1	RF
9700-A1A-BF23A		1	-6	RF
9700-C1A-BF20B		1 1	-3	RF
9700-C1A-BF200		1	-8	RF
9700-C1A-BF23A		1	-5	RF
9700-C1A-BF23B		1	-7	RF
9700-C1A-BF23C		1	-88	RF
9700-C1A-BF?3D		1	-8A	RF
9700-C1A-F23BN		1 1	-80	RF
9700-C18-8F23D		1	-4	RF
9700-F1A-BF23BN		1	-80	RF
9800 SERIES		1	-2	RF
9800-101A-E20A		1	-9	RF
9800-1C1A-E209		1	-13	RF
9800-1C1A-F20A		1	-9A	RF
9800-101A-F20B		1	-15	RF
9800-2C1A-E2GA		1 1	-14	RF
9800-201A-E208		1 1	-12	RF
9800-201A-E200		1	-12A	RF
9800-2C1A-E20D		1	-10	RF
9800-2C1A-E23A		1	-11	RF
9800-201A-F23A		1	-15A	RF
9800-2C1A-X0M		1	-16A	RF
9800-2C1A-X0X		1	-16	RF
9800-201A-BF23A		1	-17	RF
9800-201A-EZ3AM		1	-17A	RF
9800-201A-F23AM		1	-17B	RF

### HILLS



9700/9800 Series Portable Cylinder Assemblies Figure 1

# SMILL

FIG.	PART NUMBER	AIRLINE STOCK NO.	437/5/7	NOMENCL	ATURE	CODE	UNIT: PER ASSY
	0700 050150		1234567		400W		K331
1-1	9700 SERIES			CYLINDER			
-2	9800 SERIES			CYLINDER			0.5
-3	9700-C1A-		PURTABLE	CYLINDER	Y221		RF
-4	9700-C1B- BF230		PORTABLE	CYLINDER	ASSY	1	RF
-5	9700-C1A- BF23A		PORTABLE	CYLINDER	ASSY	1	RF
-6	9700-A1A- BF23A		PORTABLE	CYLINDER	ASSY	1	RF
-7	9700-C1A- BF23B		PORTABLE	CYLINDER	ASSY	1	RF
-8	9700-C1A- BF20D		PORTABLE	CYLINDER	ASSY	1	RF
-8A	9700-C1A-		PORTABLE	CYLINDER	ASSY	1	RF
-88	9700-C1A- BF23C		PORTABLE	CYLINDER	ASSY	1	RF
-8c	9700-C1A- F238N		PORTABLE	CYLINDER	ASSY	1	RF
-80	9700-F1A- BF238N		PORTABLE	CYLINDER	ASSY	1	RF
-9	9800-1C1A-		PORTABLE	CYLINDER	ASSY	1	RF
-9A	9800-1C1A- F20A		PORTABLE	CYLINDER	ASSY	1	RF
-10	9800-2¢1A-		PORTABLE	CYLINDER	ASSY	1	RF
-11	9800-201A-		PORTABLE	CYLINDER	ASSY	1	RF
-12	9800-2C1A- E208			CYLINDER		1	RF
-12A	9800-201A- E200			CYLINDER		1	RF
-13	9800-101A- E209			CYLINDER			RF
-14	9800-201A- E20A			CYLINDER			RF
-15	9800-101A- F208			CYLINDER			RF
-15A	9800-2¢1A- F23A		FURTABLE	CYLINDER	A-3-3-1		RF

<sup>-</sup> ITEM NOT ILLUSTRATED

# anu

ITEM	PART NUMBER	STOCK NO.	1234567		ASSY
1-16	9800-201A- xox		PORTABLE CYLINDER ASSY	1	RF
-16A	9800-201A-		PORTABLE CYLINDER ASSY	1	RF
-17	9800-201A- BF23A		PORTABLE CYLINDER ASSY	1	RF
-17A	9800-201A- E23AM		PORTABLE CYLINDER ASSY	1	RF
-17B	9800-201A- F23AM		PORTABLE CYLINDER ASSY	1	RF
18	5602		. CONNECTOR ASSY	2	1
19	5601		. ELBOW ASSEMBLY	2	1
20	801242-01		. REGULATOR-DEMAND	Z,BA	1
			(SEE IPL FIGURE 2 FOR BREAKDOWN)		
-21	801242-D2		. REGULATOR-DEMAND (SEE IPL FIGURE 2 FOR BREAKDOWN) ATTACHING PARTS	2,88	1
22	59602-00			12	4
22			- SCREW	16	4
	DELETED				
24	10001296		. BRACKET	2	1
25	13160		- CLAMP	S	11
26	801660-00		- HARNESS	14,E	1
-27	801658-00		. HARNESS ATTACHING PARTS	5,F	1
28	13160		. CLAMP	4	1
29	5009-00		. OUTLET ASSY (SEE IPL FIGURE 4 FOR BREAKDOWN)	5,G	2
-30	5009-00		. OUTLET ASSY (SEE IPL FIGURE 4 FOR BREAKDOWN)	2,G	1
-31	5041-00		- OUTLET ASSY (SEE IPL FIGURE 3 FOR BREAKDOWN)	5,H	2
-32	5041-00		. OUTLET ASSY (SEE IPL FIGURE 3 FOR BREAKDOWN)	2,H	1
-33	5507-00		. OUTLET ASSY (SEE IPL FIGURE 5 FOR BREAKDOWN)	5,1	2
-34	5507-00		. OUTLET ASSY (SEE IPL FIGURE 5 FOR BREAKDOWN)	2,1	1
-34A	10003566		- OUTLET ASSEMBLY	2,M	1

<sup>-</sup> ITEM NOT ILLUSTRATED

# MA

#### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL


FIG. ITEM	PART NUMBER	AIRLINE STOCK NO.	NOMENCLATURE 1234567	CODE	UNIT PER ASSY
1-348	5052-00		- OUTLET ASSY (SEE IPL FIGURE 6 FOR BREAKDOWN)	4,N	1
-34C	36728-01	<b>S</b>	. OUTLET ASSEMBLY	2,P	1
-34D	36728-01		. OUTLET ASSEMBLY	5,P	4
		}		1	
-35	6818-1	)	* PLUG	6,K	
-35A	6818-00	1	PLUG	5,T	1 1
-36	10003202	<u> </u>	. PLATE-IDENTIFICATION	9	1
-36 -37	10002538		. PLATE-IDENTIFICATION	10	1
38	10002539		. PLATE-IDENTIFICATION	3	1 1
39	801160-00		- REGULATOR ASSY (SEE	0.0	1 4
37	801100-00	1		9,C	' '
1			IPL FIGURE 7 FOR		1
- 1		1	BREAKDOWN) (SUPERSEDED	i	
1		1	BY ITEM 39A) (SB 35-49)	1	i
39A	801160-03		. REGULATOR ASSY (SEE	9,C	1
		(	IPL FIGURE 7 FOR		(
					Ī
-		j	BREAKDOWN) (SUPERSEDES	}	[
		]	ITEM 39) (SB 35-49)		
-40	801160-01	Į.	. REGULATOR ASSY (SEE	7,D	1
			IPL FIGURE 7 FOR		
			BREAKDOWN) (SUPERSEDED	1	1
		1	BY ITEM-4DA) (SB 35-49)		
-40A	801160-03	ł	- REGULATOR ASSY (SEE	7.0	1
-404	001100-03			1,00	, ,
1			IPL FIGURE 7 FOR	1	}
		]	BREAKDOWN) (SUPERSEDES		
		1 .	ITEM-40)(SB 35-49)		
-41	801160-02		. REGULATOR ASSY (SEE	8,L	1
		}	IPL FIGURE 7 FOR		'
		ł			
		-	BREAKDOWN) (SUPERSEDED	1	1
		1	BY ITEM-41A) (SB 35-49)		
-41A	801160-04		- REGULATOR ASSY (SEE	8,L	1
		[	IPL FIGURE 7 FOR		
		i	BREAKDOWN) (SUPERSEDES		(
			ITEM-41) (SB 35-49)		[
-42	10002542	1	. DECAL-INSTRUCTION	5	14
43	10002543	ſ		15	
		1	- DECAL-INSTRUCTION	14	1
-44	6084-1		- CYLINDER	A	11
45	6084-20	1	- CYLINDER	В	11
		1			1
				1	
		1			1
		1 ,			
1		}			

<sup>-</sup> ITEM NOT ILLUSTRATED

35-31-55

Page 1014 Dec 20/35

### 9001



Demand Regulator Assembly, P/N 801242 Figure 2


### MI

FIG.	PART NUMBER	AIRLINE STOCK NO.	NOMENCLATURE 1234567	CODE	UNITS PER ASSY
?-1	801242-01		REGULATOR ASSY-DEMAND (SEE ITEM 20, IPL FIG. 1 FOR NHA)	BA	RF
-2	801242-02		REGULATOR ASSY-DEMAND (SEE ITEM 21, IPL FIG.1 FOR NHA)	88	RF
-3	60500		. COVER ASSEMBLY ATTACHING PARTS	BA,BB	1
4	AN515-4-3		- SCREW	BA,88	3
5	6375-05		PLATE-IDENT ATTACHING PARTS	BA,BB	1
6	MS20470A2-2		- RIVET	BA,BB	5
7	6378		PLATE-INSTRUCTION ATTACHING PARTS	BA,BB	1
8	MS20470A2-2		. RIVET	BA,BB	2
9	6050-1		COVER-CASE	BA,BB	1
10	13374-0D		- DIAPHRAGM ASSY ATTACHING PARTS	BA,89	1
11	A1215-1		- CORD	BB , AF	1
12	A-1126		- DEFLECTOR ATTACHING PARTS	BA,BB	1
13	9036		- SCREW	BA,BB	2
14	6055E		ATTACHING PARTS	BA,BB	1
15	AN515-4-4		- SCREW	BA,BB	E
16	AN936A4		- WASHER	BA,BB	2
17	6066		. WASHER	BA,BB	2
18	A1120B		. GASKET	BA,BB	
19	5603 5606		- ADAPTER	BA	
21	6812		- ADAPTER	38	1,
22	5607-3		- SCREEN - CASE-REGULATOR	BA,BB	1,

<sup>-</sup> ITEM NOT ILLUSTRATED

### SMI

#### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL



Outlet Assembly P/N 5041 Figure 3


FIG. ITEM	PART NUMBER	AIRLINE STOCK NO.	NOMENCLATURE 1234567	CODE	UNIT: PER ASSY
3-1	5041-00		OUTLET ASSY (SEE ITEM 31, IPL FIG. 1 FOR NHA)	H	RF
2	29558-1		. COVER ASSEMBLY ATTACHING PARTS	H	1
3	29557		- NUT	Н	1
4	5042-1		- CAP	н	1
5	5042-2		- WASHER	ĺĤ	1
6	5014-1		. SCREW	H	1
7	5013-1		. SCREEN	Н	1
8	EC9-5U		. CORD-GLASS (V21343)	H	AR
9	5013-1		- SCREEN	Н	1
-10	5041-1		. COUPLING ASSEMBLY	H	1
11	29567		SETSCREW	H	1
12	29550		- BODY	Н	1
13	29551		SPRING	н	1
14	29552		VALVE	Н	1
15	29553-1		. SEAT-VALVE	H	1
16	29555		SPRING	Н	2
17	29556		PIN	H	2
18	29554		- CASE	н	1

<sup>-</sup> ITEM NOT ILLUSTRATED

35-31-55

Page 1017 Mar 1/83

### SIDIL




Outlet Assembly, P/N 5009-00 Figure 4

FIG. ITEM	PART NUMBER	AIRLINE STOCK NO.	NOMENCLATURE 1234567	EFF	UNITS PER ASSY
4-1	5009-00		OUTLET ASSY (SEE ITEM 29, IPL FIG. 1 FOR NHA)	G	1
2	59447-00		. COVER-DUST	G	1
3	5014		. SCREW	G	1
4	5013		. SCREEN	G	1
5	EC9-SU	]	. CORD-GLASS (V21343)	6	AR
-6	5009-01		. OUTLET ASSEMBLY	G	1
7	10001494	j.	. STUD	G	1
8	5065-8		GASKET	6	1
9	24823		- VALVE	e	1
10	5065-6	1	SPRING	6	1
11	10001493		PORT-FLOW	G	1
12	5065~2		RING	e	1
13	5045-4		FILTER	G	1
14	5065-3		. GASKET	6	1
15	24825		. RECEPTACLE	G	1

<sup>-</sup> ITEM NOT ILLUSTRATED

### MA

#### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL



Outlet Assembly, P/N 5507 Figure 5

FIG. ITEM	PART NUMBER	AIRLINE STOCK NO.	NOMENCLATURE 1234567	CODE	UNITS PER ASSY
5-1	5507-00		OUTLET ASSY (SEE ITEM 33, IPL FIG. 1 FOR NHA)	7	RF
2	5014-1		. SCREW	J	1
3	EC9-5U		. CORD-GLASS (V21343)	J	AR
4	5013-1		. SCREEN	J	1
~5	5533		. OUTLET SUBASSY	J	1
6.	210331		GUIDE ASSY (V49315)	J	1
7	832100		. WASHER-LOCK (V49315)	J	1
8	832402		WASHER-RET (V49315)	J	1
9	614010		WASHER-SEAT (V49315)	J	1
10	520058		SEAT (V49315)	J	1
11	833012		SPRING (V49315)	J	1
12	5533-1		BODY (V49315)	J	1


- ITEM NOT ILLUSTRATED

35-31-55

Page 1019 Mar 1/83

### HODE

#### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL



Outlet Assembly P/N 5052 Figure 6


FIG. ITEM	PART NUMBER	AIRLINE STOCK NO.	NOMENCLATURE 1234567	CODE	UNITS PER ASSY
6-1	5052-00 🔨		OUTLET ASSY (SEE ITEM 348, IPL FIG. 1 FOR NHA)	N	RF
. 2	5014		. SCREW-ORIFICE ADJ	N	1
3	EC9-5U	[	. CORD-GLASS (V21343)	N	AR
4	5013		. SCREEN	N	2
5	5058	l .	. WASHER	N	11
-6	5052-2		. COUPLING	N	1
7	5067-1		BASE	N	1
Ś	5067-2		. GASKET-BODY	N	1
9	5067-4	1	SPRING	N	1
10	5067-7		. SEAT-VALVE	N	1
11	5067-6		. GASKET-VALVE SEAT	N	1
12	5067-5	1	RETAINER	N	1
13	5067-3		- BODY	N	1
re	is item and its quired, outlet a sembly.	components no ssembly shall	longer available. If repl be replaced by a different	acements style o	are

.

<sup>-</sup> ITEM NOT ILLUSTRATED

### **ann**

#### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL



Regulator Assembly P/N 801160 Figure 7

35-31-55 Page 1021 Mar 1/83

# SWII

FIG.	PART NUMBER	STOCK NO.	NOMENCLATURE 1234567	CODE	UNIT: PER ASSY
7-1	801160-00		REGULATOR ASSY (SEE ITEM	C	1
		1	39, IPL FIGURE 1 FOR NHA)		i i
			(SUPERSEDED BY ITEM-2A)		
į			(SB 35-49)		
-2	801160-01		REGULATOR ASSY (SEE ITEM	D	1
			40, IPL FIGURE 1 FOR NHA)	1	
i			(SUPERSEDED BY ITEM-2A)		1
1			(SB35-49)		
-2A	801160-03		REGULATOR ASSY (SEE ITEM	R	1
			48A, IPL FIGURE 1 FOR NHA)		
1			SUPERSEDES ITEMS 1		
			AND 2) (SB 35-49)		
-3	801160-02		REGULATOR ASSY (SEE ITEM	L	1
			41, IPL FIGURE 1 FOR NHA)		
			(SUPERSEDED BY ITEM -3A)		
1			(SB 35-49)		
-3A	801160-04		REGULATOR ASSY (SEE ITEM	S	1
			-41A, IPL FIGURE 1 FOR NHA)		
- 1			(SUPERSEDES ITEM 3)		1
- 1			(SB 35-49)		
-4	5520-15		. VALVE KIT-ON-OFF	CDL	1
-4A	5520-16		. VALVE KIT-ON-OFF	RS	1
5	22427-1		PLATE-ID	CDLRS	1
6	23274-05	-	HANDLE	CDLRS	1
			ATTACHING PARTS		
7	AN345C10		NUT	CDLRS	1
8	AN960C10L		WASHER	CDLRS	1
_ [					
9	22445-1		WASHER-BOWED	CDLRS	1
10	5511		WASHER-FLAT	CDLRS	2
11	23394-01		NUT-PACKING	CDLRS	1
12	59598-00		- PACKING-PREFORMED	CDL	1
12A	55620-01		PACKING-PREFORMED	RS	1
4-			(SB35-49)		
13	5513		STEM ASSEMBLY	CDLRS	1
14	5517		SEAT-TEFLON	CDLRS	1
15	5518		HEAD ASSEMBLY	CDL	1
15A	802883-01		HEAD ASSEMBLY	RS	1
14	19077-04		(SB35-49)		
16	18037-01		PACKING-PREFORMED	CDL	1
16A	55620-02		PACKING-PREFORMED	RS	1
17	27707-4		(SB35-49)	CDLRS	
	23393-1		BUSHING		1
18	5522		. FILTER	CDLRS	1
	5016		. CAP-FILLER	CDLRS	11

<sup>-</sup> ITEM NOT ILLUSTRATED

### III

#### 9700 & 9800 SERIES COMPONENT MAINTENANCE MANUAL WITH IPL

FIG. ITEM	PART NUMBER	AIRLINE STOCK NO.	. NOMENCLATURE	CODE	UNIT PER ASSY
7 20	5023		. SEAT-FILLER CAP	CDLRS	1
21	5093-01		. VALVE ASSY-CHARGING	CDLRS	1
22	8385		. FILTER	CDLRS	2
23	8384		. FILTER	CDLRS	1
-24	801421-00		. OUTLET ASSY-SAFETY	CDLRS	1
25	26565		CAP	CDLRS	1
26	7171-00		DISC-SAFETY	COLRS	1
27	6555		. GASKET	CDLRS	1
28	26567		. PLUG-SAFETY	CDLRS	•
29	6370		- WASHER	CDLRS	1
30	2661-03		. GAUGE	CDLRS	1
31	5043-14		. VALVE ASSY-RELIEF	CDLRS	4
32	5056		. PLATE-IDENTIFICATION	CDLRS	1
			ATTACHING PARTS	COLKS	'
33	59553-00		. SCREW.	CDLRS	2
34	37008-01		. SETSCREW	CDLRS	1
35	5005-01		. CASE	CDL	1
35A	5005-03		. CASE (SB35-49)	RS	1
36	8561		. GUIDE	CDLRS	1
37	5003		. SPRING	CDLRS	1
38	5034		- PLATE-DIAPHRAGM	CDLRS	1
39	5033	000	. RING	CDLRS	3
40	5032-1		. DIAPHRAGM	CDLRS	1
41	5031		. PLATE-THRUST	CDLRS	1
42	5030-1		. HOLDER	CDLRS	1
43	5029		. SEAT	CDL	1
43A	803129-01		. SEAT ASSEMBLY (SB35-49)	RS	1
44	5028		. PIN	CDLRS	1
45	5002		. GUIDE	CDLRS	1
46	5027		. SPRING	CDLRS	1
47	5018		. TUBE	CDLRS	1
48	10002408		. PLATE	CDLRS	1
			ATTACHING PARTS		
49	18341		. SCREW-DRIVE	CDLRS	2
50	5053-07		. BODY	c	1
-51	10003209		. BODY	D	1
-52	10003319		. BODY	Ł	7
53	27170-01		. BODY (\$835-49)	R	h
-54	27170-02		. BODY (SB35-49)	S	7

<sup>-</sup> ITEM NOT ILLUSTRATED

The state of the s