

### 283 SERIES

### CONSTANT FLOW MASK ASSEMBLIES

### CLEANING PROCEDURE

#### WARNING:

IMPROPER USE OR IMPROPER MAINTENANCE OF THIS EQUIPMENT MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH. THESE ASSEMBLIES ARE INTENDED TO BE USED ONLY FOR AVIATION APPLICATIONS AS COMPONENTS OF A COMPLETE AVIATION OXYGEN SYSTEM USED ONLY BY, OR UNDER THE SUPERVISION OF, A PILOT OR CREW MEMBER TRAINED AND QUALIFIED IN ITS USE. THIS EQUIPMENT IS TO BE SERVICED ONLY BY SERVICE TECHNICIANS TRAINED IN THE INHERENT HAZARDS OF HIGH PRESSURE AVIATION OXYGEN AND KNOWLEDGEABLE IN THIS EQUIPMENT. THE NAMES OF AUTHORIZED SERVICE CENTERS ARE AVAILABLE FROM SCOTT AVIATION OR YOUR AUTHORIZED SCOTT DISTRIBUTOR. THIS EQUIPMENT IS TO BE USED ONLY WITH AVIATION BREATHING OXYGEN PER MIL-PRF-27210.



#### PROCEDURE

#### CAUTION:

DO NOT USE WATER HEATED TO MORE THAN 140°F (60°C). AVOID GETTING WATER INSIDE RESERVOIR BAG.

- A. Clean all external surfaces of the mask using a warm soapy water solution made from one-half teaspoon (2.4 cc) mild household type detergent to one gallon (3.8 liters) clean water.
- B. Rinse all parts with clean, cold water.
- C. Wipe excess water from the mask using a lint-free cloth, preferably gauze.
- D. Air dry mask.
- E. Wipe mask assembly with a lint-free cloth soaked in Isopropyl Alcohol (70% min.). Pay particular attention to the inside of the facepiece and the face seal. Remove excess alcohol with clean, lint-free cloth.
- F. Air dry mask.